



Broadcast Electronics

4100 North 24th Street, Quincy, Illinois 62305 USA • Phone (217) 224-9600 • Fax (217) 224-9607 • www.bdcast.com • bdcast@bdcast.com



ASI 10 AM IBOC DIGITAL SIGNAL GENERATOR

Version 4.3.2
Instruction Manual

597-0542-003
Rev C
October 13, 2011

ASI 10 AM IBOC DIGITAL SIGNAL GENERATOR

Version 4.3.2 Instruction Manual

©2011 Broadcast Electronics. All rights reserved.

The information in this publication is subject to improvement and change without notice. Although every effort is made to ensure the accuracy of the information in this manual, Broadcast Electronics accepts no responsibility for any errors or omissions. Broadcast Electronics reserves the right to modify and improve the design and specifications of the equipment in this manual without notice. Any modifications shall not adversely affect performance of the equipment so modified.

Proprietary Notice

This document contains proprietary data of Broadcast Electronics. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, translated into any other language in any form or by any means, electronic or mechanical, including photocopying or recording, for any purpose, without the express written permission of Broadcast Electronics.

Trademarks

Broadcast Electronics and the BE logo are registered trademarks of Broadcast Electronics.

"iBiquity" and "iBiquity Digital" are trademarks of iBiquity Digital Corporation.

"HD Radio" is a trademark of iBiquity Digital Corporation.

The term "PAC" is an iBiquity-licensed trademark of Lucent Technologies, Inc.

The iBiquity Digital corporate logo is a trademark of iBiquity Digital Corporation.

All other trademarks, whether claimed or registered, are the exclusive property of their respective owners.

Broadcast Electronics Product Warranty (Two-Year Limited)

BE hereby warrants all new products manufactured by BE against any defects in material or workmanship at the time of delivery thereof, or that develop under normal use within a period of two (2) years from the date of shipment.

BE reserves the right to repair equipment under warranty with new or refurbished equipment or parts. BE's sole responsibility with respect to any equipment or parts not conforming to this warranty is to replace or repair such equipment upon the return thereof F.O.B. to BE's factory in Quincy, Illinois, U.S.A. In the event of replacement pursuant to the foregoing warranty, only the unexpired portion of the warranty from the time of the original purchase will remain in effect for any such replacement.

This warranty shall exclude the following products, component parts and/or assemblies:

- (a) Transmitter power output tubes shall only carry the original manufacturers' or suppliers' standard warranty in effect on their original shipment date.
- (b) All computers, computer peripherals, cables, hard disk drives, etc., shall only carry the manufacturers' or suppliers' standard warranty in effect on their original shipment date.
- (c) "Components", defined as separate and individual parts (e.g. transistors, integrated circuits, capacitors, resistors, inductors, fans, etc), resold by BE from another manufacturer or supplier, shall only carry a 90 day warranty, effective the date of shipment. Any such 'Components' being returned for warranty claim must be (1) returned in their original packaging and (2) must be in new, unused condition.
BE is unable to process or resolve component defects or performance concerns on components that have been soldered, installed, wired or in any way altered from new their new condition.
- (d) "Resale Equipment", defined as equipment purchased from another manufacturer or supplier, then resold by BE, shall only carry such manufacturer's or supplier's standard warranty in effect as of the original shipment date. All warranty claims against any and all 'resale equipment' sold by BE must be filed directly with the original equipment manufacturer. BE is unable to process or resolve equipment defects or performance concerns on products or services not manufactured by BE.

This warranty shall not extend to claims resulting from any acts of God, terrorism, war, defects or failures caused by Purchaser or user abuse or misuse, operator error, or unauthorized attempts to repair or alter the equipment in any way.

Under no circumstances shall BE be responsible for indirect, incidental or consequential damages, including, but not limited to transportation costs, non-authorized repair or service costs, downtime costs, costs for substituting equipment or loss of anticipated profits or revenue, incurred by Purchaser, whether based in contract, tort or for negligence or breach of statutory duty or otherwise.

The terms of the foregoing warranty shall be null and void if the equipment has been altered or repaired without specific written authorization from BE, or if not installed according to BE's instruction manuals, including, but not limited to, the absence of proper grounding, surge (TVSS) protection on the AC circuit panel or proper lightning protection/grounding on all output circuits, or if equipment is operated under environmental conditions or circumstances other than those specifically described in BE's product literature or instruction manual which accompany the equipment. **The warranty shall be voided if the product or subassembly is equipped with a tamper seal and that tamper seal is broken.** BE shall not be liable for any expense of any nature whatsoever incurred by the original user without prior written consent of BE. The warranty provided herein shall terminate at the end of the period set forth above. **This warranty extends only to the original Purchaser and is not transferable.** There are no third party beneficiaries of any of the provisions of this warranty. If the equipment is described as "used" equipment, it is sold as is and where is and no warranty applies unless authorized in writing.

EXCEPT AS SET FORTH HEREIN, AS TO TITLE AND AS SPECIFICALLY REQUIRED BY LAW, THERE ARE NO OTHER WARRANTIES, OR ANY AFFIRMATIONS OF FACT OR PROMISES BY BE, WITH REFERENCE TO THE EQUIPMENT, OR TO MERCHANTABILITY, FITNESS FOR A PARTICULAR APPLICATION, SIGNAL COVERAGE, INFRINGEMENT, OR OTHERWISE, WHICH EXTEND BEYOND THE DESCRIPTION OF THE EQUIPMENT ON THE FACE HEREOF.

IMPORTANT INFORMATION

EQUIPMENT LOST OR DAMAGED IN TRANSIT -

When delivering the equipment to you, the truck driver or carriers' agent will present a receipt for your signature. Do not sign it until you have:

1) Inspected the containers for visible signs of damage and 2) Counted the containers and compared with the amount shown on the shipping papers. If a shortage or evidence of damage is noted, insist that notation to that effect be made on the shipping papers before you sign them.

Further, after receiving the equipment, unpack it and inspect thoroughly for concealed damage. If concealed damage is discovered, immediately notify the carrier, confirming the notification in writing, and secure an inspection report. This item should be unpacked and inspected for damage WITHIN 15 DAYS after receipt. Claims for loss or damage will not be honored without proper notification of inspection by the carrier.

RF PRODUCT TECHNICAL ASSISTANCE, REPAIR SERVICE, PARTS -

Technical assistance is available from Broadcast Electronics by letter, prepaid telephone or E-mail. Equipment requiring repair or overhaul should be sent by common carrier, prepaid, insured, and well protected. If proper shipping materials are not available, contact the RF Technical Services Department for a shipping container. Do not mail the equipment. We can assume no liability for inbound damage, and necessary repairs become the obligation of the shipper. Prior arrangement is necessary. Contact the RF Technical Services Department for a Return Authorization.

Emergency and warranty replacement parts may be ordered from the following address. Be sure to include the equipment model number, serial number, part description, and part number. Non-emergency replacement parts may be ordered directly from the Broadcast Electronics stock room at the number shown below.

RF TECHNICAL SERVICES -

Telephone: +1 (217) 224-9617

E-Mail: rfservice@bdcast.com

Fax: +1 (217) 224-6258

FACILITY CONTACTS -

Broadcast Electronics, - Quincy Facility

4100 N. 24th St. P.O. BOX 3606

Quincy, Illinois 62305

Telephone: +1 (217) 224-9600

Fax: +1 (217) 224-6258

General E-Mail: bdcast@bdcast.com

Web Site: www.bdcast.com

PARTS -

Telephone: +1 (217) 224-9617

E-Mail: parts@bdcast.com

RETURN, REPAIR, AND EXCHANGES -

Do not return any merchandise without our written approval and Return Authorization. We will provide special shipping instructions and a code number that will assure proper handling and prompt issuance of credit. Please furnish complete details as to circumstances and reasons when requesting return of merchandise. All returned merchandise must be sent freight prepaid and properly insured by the customer.

MODIFICATIONS -

Broadcast Electronics, reserves the right to modify the design and specifications of the equipment in this manual without notice. Any modifications shall not adversely affect performance of the equipment so modified.



SAFETY PRECAUTIONS

PLEASE READ AND OBSERVE ALL SAFETY PRECAUTIONS//

ALL PERSONS WHO WORK WITH OR ARE EXPOSED TO POWER TUBES, POWER TRANSISTORS, OR EQUIPMENT WHICH UTILIZES SUCH DEVICES MUST TAKE PRECAUTIONS TO PROTECT THEMSELVES AGAINST POSSIBLE SERIOUS BODILY INJURY. EXERCISE EXTREME CARE AROUND SUCH PRODUCTS. UNINFORMED OR CARELESS OPERATION OF THESE DEVICES CAN RESULT IN POOR PERFORMANCE, DAMAGE TO THE DEVICE OR PROPERTY, SERIOUS BODILY INJURY, AND POSSIBLY DEATH.



DANGEROUS HAZARDS EXIST IN THE OPERATION OF POWER TUBES AND POWER TRANSISTORS -

The operation of power tubes and power transistors involves one or more of the following hazards, any one of which, in the absence of safe operating practices and precautions, could result in serious harm to personnel.

- A. HIGH VOLTAGE** - Normal operating voltages can be deadly. Additional information follows.
- B. RF RADIATION** - Exposure to RF radiation may cause serious bodily injury possibly resulting in Blindness or death. Cardiac pacemakers may be affected. Additional information follows.
- C. HOT SURFACES** Surfaces of air-cooled radiators and other parts of tubes can reach temperatures of several hundred degrees centigrade and cause serious burns if touched. Additional information follows.
- D. RF BURNS** Circuit boards with RF power transistors contain high RF potentials. Do not operate an RF power module with the cover removed.

HIGH VOLTAGE –

Many power circuits operate at voltages high enough to kill through electrocution. Personnel should always break the primary AC Power when accessing the inside of the transmitter.

RADIO FREQUENCY RADIATION

Exposure of personnel to RF radiation should be minimized, personnel should not be permitted in the vicinity of open energized RF generating circuits, or RF transmission systems (waveguides, cables, connectors, etc.), or energized antennas. It is generally accepted that exposure to “high levels” of radiation can result in severe bodily injury including blindness. Cardiac pacemakers may be affected.

The effect of prolonged exposure to “low level” RF radiation continues to be a subject of investigation and controversy. It is generally agreed that prolonged exposure of personnel to RF radiation should be limited to an absolute minimum. It is also generally agreed that exposure should be reduced in working areas where personnel heat load is above normal. A 10 mW/cm² per one tenth hour average level has been adopted by several U.S. Government agencies including the Occupational Safety and Health Administration (OSHA) as the standard protection guide for employee work environments. An even stricter standard is recommended by the American National Standards Institute which recommends a 1.0 mW/cm² per one tenth hour average level exposure between 30 Hz and 300 MHz as the standard employee protection guide (ANSI C95.1-1982).

RF energy must be contained properly by shielding and transmission lines. All input and output RF connections, such as cables, flanges and gaskets must be RF leak proof. Never operate a power tube without a properly matched RF energy absorbing load attached. Never look into or expose any part of the body to an antenna or open RF generating tube or circuit or RF transmission system while energized. Monitor the tube and RF system for RF radiation leakage at regular intervals and after servicing.

HOT SURFACES –

The power components in the transmitter are cooled by forced-air and natural convection. When handling any components of the transmitter after it has been in operation, caution must always be taken to ensure that the component is cool enough to handle without injury.

Table of Contents

1	HD RADIO™ AM REFERENCE ASI 10	1
1.1	System Overview	1
1.2	Document Overview	1
2	ABBREVIATIONS AND CONVENTIONS	2
2.1	Abbreviations and Acronyms	2
2.2	Presentation Conventions	2
3	INSTALLATION.....	3
3.1	ASi 10 Installation	3
3.2	Checking the RF Transmission and Antenna System	3
3.3	Modifying the Transmitter	4
3.4	IBOC System Connections.....	5
4	FRONT PANEL DESCRIPTION	6
4.1	Graphical User Interface Display/Indicator Definitions	6
4.1.1	Exciter Platform Indicator.....	8
4.1.2	Station Information	9
4.1.3	Frequency.....	13
4.1.4	Band	14
4.1.5	Status Upper Section (Main Menu Upper Right)	14
4.1.6	Status Lower Section (Main Menu Upper Right)	14
4.1.7	Audio Bypass.....	14
4.1.8	Digital Carrier Control.....	15
4.1.9	Analog Modulation	15
4.1.10	AM Layer 1 Service Mode	15
4.1.11	Date and Time.....	16
4.1.12	Exciter Status Bottom Right	18
4.2	System Tab Control Buttons	18
4.2.1	Shutdown	18
4.2.2	Configuration	19
4.2.3	Versions	21
4.2.4	Configure Password.....	22
4.2.5	Command	23
4.2.6	GPS Data	30
4.2.7	Local Time	31
4.3	Log Tab Control Buttons.....	31
4.3.1	Levels	32
4.3.2	Parameters	33
4.3.3	System Status	35
4.4	Platform Tab Control Buttons	35

4.4.1	Platform Configure	36
4.4.2	Link Status.....	36
4.5	Station Tab Control Buttons	37
4.5.1	Station Interface	38
4.5.2	Station Information Schedule	38
4.5.3	Station Information	40
4.5.4	Station Default PAD.....	40
4.5.5	Station Program Control.....	44
4.6	Audio Tab Control Buttons	44
4.6.1	Audio Levels	45
4.6.2	Analog Audio Diversity	47
4.6.3	Audio Bypass.....	49
4.6.4	Analog Audio Bandwidth	49
4.6.5	Audio Blend Control	49
4.6.6	Audio Level Control	50
4.6.7	Digital Audio Configuration	51
4.7	Signal Tab Control Buttons.....	52
4.7.1	Frequency.....	52
4.7.2	Layer 1 Service Mode.....	52
4.7.3	Signal Configuration.....	52
4.8	Test Tab Control Buttons	57
4.8.1	Bit Error Rate Mode	57
4.8.2	Single Subcarrier Mode	58
4.8.3	Test Vector Capture	58
4.9	Utility Tab Control Buttons	59
4.9.1	Screen Resize.....	59
4.9.2	Fonts	61
4.9.3	Virtual Chat	62
4.9.4	Activity Monitor.....	62
4.9.5	Up Time	63
5	OPERATING PROCEDURES.....	64
5.1	Startup	64
5.2	Audio Diversity Blend Delay Adjustment	64
5.3	Shutdown Procedure	64
5.4	Magnitude/Phase Delay Adjustment	64
5.4.1	AM Phase Delay Adjustment.....	64
5.5	IBOC System Alignment.....	66
5.6	Remote GUI Control	69
5.7	Telco Dialup	74
6	SOFTWARE UPGRADE	75
6.1	Software Upgrade Overview	75
6.1.1	Software Upgrade Detail	75
7	BE PART NUMBERS	81

8 RF TECHNICAL SERVICES CONTACT INFORMATION96

9 DRAWINGS97

9.1 Introduction 97

1 HD Radio™ AM Reference ASi 10

1.1 System Overview

Broadcast Electronics uses the IBOC (in-band-on-channel) digital broadcasting system from iBiquity Digital Corporation now known as HD Radio. The system is designed to permit a smooth evolution from current analog amplitude modulation (AM) and frequency modulation (FM) radio to a fully digital IBOC system. This system delivers digital audio and data services to mobile, portable, and fixed receivers from terrestrial transmitters in the existing medium frequency (MF) and very high frequency (VHF) radio bands. Broadcasters may continue to transmit analog AM and FM simultaneously with the new, higher-quality and more robust digital signals, allowing themselves and their listeners to convert from analog to digital radio while maintaining their current frequency allocations. The ASi 10 is Broadcast Electronics' AM HD Radio Generator, used to create the HD signal overlaid with the AM signal.

1.2 Document Overview

This document provides a description of controls and indicators, system interconnection and operating procedures for the ASi 10 AM IBOC Digital Signal Generator.



2 Abbreviations and Conventions

2.1 Abbreviations and Acronyms

AES/EBU	Audio Engineers Society / European Broadcast Union
ALFN	Absolute L1 Frame Number
AM	Amplitude Modulation
BER	Bit Error Rate
CD	Compact Disk
CD-ROM	CD/Read Only Memory
FCC	Federal Communications Commission
FM	Frequency Modulation
GEL	Gateway to Exciter Link – Exciter = ASi 10
GPS	Global Positioning System
GUI	Graphical User Interface
IBOC	In-band On-channel
L1	Layer 1
MF	Medium Frequency
MP1–MP7	Primary Service Modes 1 through 7
MS1–MS4	Secondary Service Modes 1 through 4
PAC	Perceptual Audio Coder
PAR	Peak-to-Average Ratio
RF	Radio Frequency
VHF	Very High Frequency

2.2 Presentation Conventions

Unless otherwise noted, the following conventions apply to this document:

- Information enclosed in braces { } is either unavailable at the present time or subject to change.
- All vectors are indexed starting with 0.
- The element of a vector with the lowest index is considered to be first.
- In drawings and tables, the leftmost bit is considered to occur first.
- Bit 0 of a byte or word is considered the least significant bit.
- In representations of binary numbers, the least significant bit is on the right.
- When presenting the dimensions of a matrix, the number of rows is given first (e.g., an n x m matrix has n rows and m columns).
- In timing diagrams, earliest time is on the left.



3 Installation

Installation of the ASi 10 IBOC digital signal generator consists of: 1) installing the unit in a rack, 2) checking the ATU and antenna system, 3) modifying the transmitter, and 4) connecting the ASi 10 to the digital link, audio processing equipment, and the transmitter. Refer to the following text to install the ASi 10 and configure the AM system for IBOC transmission.

3.1 ASi 10 Installation

The ASi 10 may be installed in any convenient location in a 19 inch (48.3 cm) rack within reach of the transmitter, STL link, and audio processing equipment. The unit requires 7 inches (17.78 cm) of rack space. Once a rack location is determined, mount the chassis in the rack using 4 screws.

3.2 Checking the RF Transmission and Antenna System

The station RF transmission and antenna system may present problems for transmitting the AM IBOC signal. Generally, the most common problems are related to system linearity. Non-linearity can be caused by: 1) the transmission/radiating system presenting a non-optimized RF load to the transmitter, 2) bandwidth restrictions in the phasing, tuning, and radiating system. Non-optimized antenna systems traditionally are subject to such problems and do not lend themselves to IBOC transmission.

Prior to attempting to implement IBOC transmission, it is recommended that the antenna system be optimized to ± 15 kHz. Specific attention should be made to the ± 5 kHz region. Facilities with full quarter, half or 5/8 wave non-directional radiators generally experience few bandwidth problems and are good candidates for IBOC implementation. The following text presents some general recommendations:

1. For directional stations, the following information will be required to check/analyze antenna system performance.
2. A recent common point impedance sweep.
3. Pattern parameters such as tower height, spacing, and field ratios.
4. A phasor schematic.
5. Directional patterns should be optimized to minimize pattern modulation in the main lobes.
6. Reduce pattern modulation for Day & Night patterns between nulls. No minimum performance is yet specified. Pattern modulation is the change in the shape of the horizontal plane polar pattern. This is caused by different performance of the antenna system at different frequencies within the modulation bandwidth. Pattern modulation has four primary causes:
7. Frequency-dependent phase shifts and changes in power division introduced by the power division and phase-shift networks within the phasor.
8. Frequency-dependent phase shifts in the feedlines.
9. Frequency-dependent phase shifts introduced by the matching networks within the Line Tuning Units.
10. Changes in the tower geometry with frequency.
11. A polar pattern which changes significantly with frequency, will deliver an asymmetrical modulation spectrum to a distant receiver. The digital portion of the IBOC waveform is representative of a rectangular modulation spectrum delivered to the common point. Changes through the antenna system will cause the received spectrum to appear trapezoidal in the far field. IBOC signal generator and receiver equalization will address these issues, however best digital performance is achieved with a flat frequency response.

12. It is not possible, especially when deep nulls are present, to minimize pattern modulation in all directions of the compass at the same time. For that reason, it is important to identify those angular spans of the polar pattern where superior performance is most valuable and to concentrate on optimizing the performance within those angular spans.
13. As part of the rule making concerning AM IBOC, iBiquity has recommended a reduction in the bandwidth of the maximum analog modulating frequency from 10 kHz to 5 kHz. Extensive experimental operation of the AM IBOC system has shown that the performance of the system is primarily dominated by symmetry in the region ± 5 kHz removed from the carrier. This is less than the ± 10 kHz bandwidth needed for present analog operation.

At this point, no exact specifications have been determined for RF transmission and antenna performance. Prior to configuring the system for IBOC operation, it is recommended the user contact the Broadcast Electronics Customer Service Department for assistance in evaluating the RF transmission/antenna system. The service group can provide information for determining the required performance for an IBOC transmission system.

3.3 Modifying the Transmitter

To broadcast the IBOC signal, the Broadcast Electronics A-Series and E-Series AM transmitters must be modified. The modifications consist of: 1) installing modulation level circuit board 919-0561, 2) jumper programming on the exciter circuit board, and 3) installing IBOC bypass circuit board assembly 919-0560. Modification kit 957-0100 provides the parts and information required to modify the transmitter. Refer to the documentation in kit 957-0100 and perform the procedures to modify the transmitter exciter circuit board.



3.4 IBOC System Connections

The ASi 10 is part of an IBOC broadcasting system. This system consists of several pieces of equipment. Connection diagrams 597-0541-77 and 597-0541-78 in SECTION 8 DRAWINGS present system wiring for the Broadcast Electronics A-Series and E-Series AM transmitters. Refer to SECTION 8 and the following checklist to connect the ASi 10 system.

AM System Checklist

Refer to wiring diagram 597-0541-77/78 found in Section 8 at the back of this manual.

- ☐ Install ASi 10 in a rack close to the transmitter (12' cables are supplied).
- ☐ Connect 1PPS Out on ASi 10 to 1PPS In on ASi 10
- ☐ Connect GPS Data Out on ASi 10 to GPS Data In on ASi 10
- ☐ Connect AES/EBU Out from Studio to Studio AES In on the ASi 10
- ☐ Connect Data Out from the studio to IBOC DATA on the ASi 10 if available
- ☐ Connect AM AES out from the ASi 10 to your analog audio processor's AES/EBU In
- ☐ Connect AM AES/EBU out from your analog processor to the AM/FM AES In on the ASi 10
- ☐ Connect the analog out from the analog processor to the AM Audio In on the ASi 10
- ☐ Connect the IBOC AES Out on the ASi 10 to the IBOC AES/EBU in on your digital audio processor
- ☐ Connect the IBOC AES/EBU Out of your digital audio processor to the IBOC AES In on the ASi 10
- ☐ Connect the GPS antenna to the GPS ANT In if available
- ☐ Mount and connect the IBOC Bypass Circuit assembly on your AM transmitter as shown in drawings 597-0541-77/78 in Section 8 of this manual.
- ☐ Connect P9 from ASi 10 to IBOC Bypass circuit on transmitter
- ☐ Wire red/black wire to pin 30 on TB-1/2 on the back of the transmitter as shown in drawing 597-0541-77/78 in Section 8 of this manual.
- ☐ Wire ground lug off P9 to screw on back of ASi 10
- ☐ Plug in P3 to Audio Bypass on back of ASi 10
- ☐ Connect coax from J1 on the IBOC Bypass circuit to the External Stereo Input on the transmitter
- ☐ Connect coax from AM Phase out on the ASi 10 to J3 on the IBOC Bypass Circuit on the back of the transmitter.
- ☐ If your Studio to Transmitter Link (STL) can support 4kbps of data you can send song artist and title information over the link. Connect the data output from the STL to the IBOC data input on the ASi 10. The input data stream must use the SLIP protocol. This type of data can also be sent via Ethernet or Modem.

ASi 10 AC Power Connections. *Warning!!!* The ASi 10 can operate on either 110VAC or 220VAC. It is configured from the factory for 220VAC operation. If you are using a UPS to back up the ASi 10 ensure the voltage input switch is in the proper position prior to applying power and turning on the unit, otherwise damage may result !



4 Front Panel Description

Front panel descriptions are divided into two categories; Display/Indicator Definitions and Control Buttons. In all windows the following general rules apply:

1. Read only fields have a light blue background.
2. Read/Write fields have a blue-green background.
3. On data entry screens the Cancel button will not make any entered data permanent. Any screen with a Cancel button will also have an OK button that can be used to make data permanent.
4. On data entry screens the Close button only closes the window, any data that has been specified is already permanent because it was registered as entered.
5. On Numeric keyboard screens the valid range of data will be displayed.
6. Failures that need attention are displayed in RED.
7. Warnings are displayed in Yellow.
8. Normal status information is displayed in Green.

4.1 Graphical User Interface Display/Indicator Definitions

Figure 4-1 is the HD Radio AM Exciter Graphical User Interface (GUI) display screen: This screen is displayed upon system stabilization. Descriptions of Display/Indicator fields for this screen are provided in the following subparagraphs.

Figure 4-2 is the HD Radio AM Exciter Activity Monitor screen: This screen is displayed if no GUI interaction is detected for greater than 1 minute.

The first four lines depict the status of the four AES audio ports, Analog Input, Analog Output, Digital Input, and Monitor Output. These lights will blink from black to green as long as there is audio on each port. If silence is detected the light will remain black.

The Analog input and Digital input Fault lights should remain black during normal operation. If the AES stream at either port is not detected the light will turn Red indicating the Fault.

The Exporter Link activity monitor does not apply to the Generation 2 Exciter.

The Digital Up Converter activity monitor will blink from black to green as long as data is exchanged with the DUC. If no DUC data activity is detected this light will remain black.






Figure 4-1: GUI Interface Screen




Figure 4-2: GUI Interface Activity Monitor Screen

4.1.1 Exciter Platform Indicator

This identifies the present system platform. When selected a platform menu is displayed as shown in Figure 4-3.

To change the exciter platform select the desired setting and press Restart button. The system application will now be restarted as the new platform type. To exit the menu with no changes select Cancel to exit.

NOTE: The platform selected must be compatible with the hardware in use or errors will occur.




Figure 4-3: Platform Configuration Screen

4.1.2 Station Information

The Station Call Sign indicator displays the call sign being transmitted with the digital data. When selected, the Station Information screen (Figure 4-4) is displayed.

The Station Information screen is subdivided into 4 group boxes: Station Identification, Call Sign, Station Slogan, and Station Message.

VNC: Hemlock.ibiquity.com

Station Information

Station Identification

FCC ID Country Code

US

Call Sign

Standard Universal

HD

Station Slogan

Standard Universal

HD Radio...www.HD-Radio.com

☒ Enable both standard and universal formats

Station Message

HD Radio...www.HD-Radio.com ISO 8859-1

☐ High Priority

OK Cancel

Warning: Applet Window

Figure 4-4: Station Information Screen

4.1.2.1 Station Identification

4.1.2.1.1 Country Code

The Country Code tab, when selected, displays a Numeric Keyboard screen similar to Figure 4-8. To change the Country Code, enter the desired Country Code using the number keys. Press *Enter* to establish the new Country Code and return to the Station Information screen.

4.1.2.1.2 FCC ID

The (Federal Communications Commission) FCC ID field, when selected, displays a Numeric Keyboard screen (Figure 4-8). To change the FCC ID, enter the desired FCC ID using the number keys. Press *Enter* to establish the new FCC ID and return to the Station Information screen.

4.1.2.2 Call Sign

There are 2, mutually exclusive, methods for transmitting a station's call signs: Standard & Universal.

4.1.2.2.1 Standard

NOTE: The Standard Call Sign field is limited to four characters; all characters **MUST** be upper case.

The Standard Call Sign field, when selected, displays a Alphanumeric Keyboard screen similar to Figure 4-6. To change the Standard Call Sign, enter the desired letters. Selecting shift, type the desired four-character Call Sign using the character keys. Press *Enter* to establish the new call sign and return to the Station Information screen.

4.1.2.2.2 Universal

If a station's call sign is longer than 4 characters, or contains international symbols, the Universal Call sign should be used. The Universal Call Sign supports 2 different character sets: ISO8859-1 and Unicode. Use the drop down box (as shown in Figure 4-5) to select the desired character set. The Universal Call Sign field, when selected, displays an Alphanumeric Keyboard screen similar to Figure 4-6. To change the Universal Call Sign, enter the desired letters. Press *Enter* to establish the new call sign and return to the Station Information screen. If "Append Band" is selected (checked), the current frequency band will be appended to the Universal Call Sign that is displayed at the receiver.

4.1.2.3 Station Slogan

There are 2 methods for transmitting a Station Slogan: Standard & Universal. Unlike the Call Sign, both methods can be transmitted simultaneously. However, if they are transmitted simultaneously, the entries must be identical. If "Enable both standard and universal formats" is selected (checked) then the Universal Station Slogan entry is grayed out and displays the contents of the Standard Slogan.

4.1.2.4 Standard Station Slogan

NOTE: The Standard Station Slogan field is limited to 56 characters.

The Standard Station Slogan tab, when selected, displays a Alphanumeric Keyboard screen, similar to Figure 4-6. To change the Standard Station Slogan, enter the characters using the Alphanumeric Keyboard. Press *Enter* to establish the new Standard Station Slogan and return to the Station Information screen.

VNC: Hemlock.ibiquity.com

Station Information

Station Identification

FCC ID Country Code

US

Call Sign

Standard Universal

HD-Radio ISO 8859-1

UNICODE

ISO 8859-1

Station Slogan

Standard Universal

HD Radio...www.HD-Radio.com

☒ Enable both standard and universal formats

Station Message

HD Radio...www.HD-Radio.com UNICODE

☐ High Priority

OK Cancel

Warning: Applet Window

Figure 4-5: Universal Call Sign and Station Slogans

4.1.2.4.1 Universal Station Slogan

If a station's slogan is longer than 56 characters, or contains international symbols, the Universal Station Slogan should be used. The Universal Station Slogan supports 2 different character sets: ISO8859-1 and Unicode. Use the drop down box (as shown in Figure 4-5) to select the desired character set. The Universal Station Slogan tab, when selected, displays an Alphanumeric Keyboard screen similar to Figure 4-6. To change the Universal Station Slogan, enter the desired characters and press *Enter* to establish the new slogan and return to the Station Information screen.

4.1.2.5 Station Message

The Station Message field is used to transmit messages other than the call sign or station slogan. The Station Message field supports 4 different character sets: RBDS/RDS E.1, RBDS/RDS E.2, RBDS/RDS E.3, and Unicode. Use the drop down box (as shown in Figure 4-5) to select the desired character set. The Station Message field, when selected, displays an Alphanumeric Keyboard screen similar to Figure 4-6. To change the Station Message, enter the desired characters and press *Enter* to establish the new Station Message and return to the Station Information screen.

Check the "High Priority" box to indicate to receivers that current message has a high priority.




Figure 4-6: Alphanumeric Keyboard

4.1.3 Frequency

Frequency indicates the carrier center frequency. Select this option to change the carrier frequency. The Numeric Keyboard, Figure 4-8, is displayed. To change the frequency, enter the desired frequency using the number keys. Press *Enter* to establish the new frequency.

For the new value to take effect the system must be rebooted. A screen will prompt you to restart, Figure 4-7, press Yes to restart with the new frequency.



Figure 4-7: Frequency Change Restart Screen




Figure 4-8: Numeric Keyboard

4.1.4 Band

The main menu frequency band indicator displays the exciter waveform selection: AM or FM.

4.1.5 Status Upper Section (Main Menu Upper Right)

The upper section displays current exciter state. Either Operational in Green or Non-Operational in Red.

4.1.6 Status Lower Section (Main Menu Upper Right)

The lower section displays current exciter Alarm state. Either No Alarm in Green or Alarm in Red. The Alarm can be cleared by selecting this area or the Station Interface section.

4.1.7 Audio Bypass

The Audio Bypass indicator displays None, Bypass A, Bypass B or Bypass A&B. When Audio Bypass is selected, the Audio Bypass selection screen is displayed, (Figure 4-9).

NOTE: The EASU Audio toggle switches **MUST** be in the Auto position and Station Interface Outputs 13 and 14 must be connected to the EASU to enable this function.




Figure 4-9: Audio Bypass Selection Screen

4.1.7.1 Audio-A Bypass

When on; The Exciter Station Interface Output 13 closes to switch the Exciter Auxiliary Service Unit (EASU) to the Bypass position. When off; The Exciter Station Interface Output 13 is determined by the software.

4.1.7.2 Audio-B Bypass

When on, Exciter Station Interface Output 14 closes to switch the Exciter Auxiliary Service Unit (EASU) to the Bypass position. When off, Exciter Station Interface Output 14 is determined by the software.

4.1.7.3 Auto Startup

When Auto Startup is selected, the audio bypass switches toggle to the delayed state to begin the audio ramp function (see paragraph 4.6.2.5). This overrides the Audio Bypass selection. If Auto Startup is not selected, the audio bypass switches toggle to the state defined by the Audio Bypass selection.

4.1.7.4 Auto Shutdown

When Auto Shutdown is selected, upon an error condition or receipt of a shutdown command, the audio bypass switches toggle to the Bypass state. This overrides the Audio Bypass selection. If Auto Shutdown is not selected, the audio bypass switches remain in the state defined by the Audio Bypass selection.

4.1.8 Digital Carrier Control

This indicator displays whether the digital subcarriers are on or off. All active IBOC digital subcarriers are added or removed by selecting On or Off.

4.1.9 Analog Modulation

The Analog Modulation indicator displays the state of the analog modulation On or Off. Selecting Off effectively reduces the modulation to 0%, leaving only the carrier. When the analog modulation is On the modulation percentage is controlled via the analog gain setting (see Section 4.7.3.8).

4.1.10 AM Layer 1 Service Mode

The AM Layer 1 Service Mode indicator displays the current service mode of operation.

If selected when not in BER mode the Dialog Box, Figure 4-10: Dialog Box, is displayed. Select OK to return to the main menu.



Figure 4-10: Dialog Box

When the AM Layer 1 Service Mode is selected when in BER Mode, see paragraph 4.8.1, the AM Service Mode screen, Figure 4-11, is displayed.

Select the appropriate AM service mode, MA1 or MA3 and click *Ok* to activate the selection.




Figure 4-11: AM Service Mode Screen

4.1.11 Date and Time

Date and time displayed are local time. To obtain the Global Positioning System (GPS) and use it for display in the lower-left corner of the main menu, see Sync Local Time below. If the GPS is not connected to an antenna with access to GPS data, this window will display a time/date of 00:00:00 Jan 6, 1980 and increment from that time until the system attains GPS time lock.

When selected, the Local Time insertion screen is displayed, Figure 4-12. This screen is broken up into 4 different group boxes: Date & Time Settings, Time Zone, Daylight Savings Time, and GPS Time Synchronization.




Figure 4-12: Local Time Insertion Screen

Date & Time Settings: This area allows manual entry of local time.

Time Zone: This area allows setting of the local time zone. If the Country/Region selection is None/Other the zone will be set to Universal (UTC) and an offset from UTC can be entered using the "UTC Offset" drop down box. Values from -12 to 12 are valid and are entered using a numeric keypad similar to Figure 4-8.

Daylight Savings Time: This area allows the enabling of daylight savings time parameters if Time Zone Info selection is not None/Other. Checking "Enabled" will use daylight savings time based on the zone selected. Unchecking "Enabled" indicates to the receiver that daylight savings time is not to be used in regardless of the "Time Zone Info"/"Zone" selections. Changing the Time Zone Info and/or the DST Enable button will require the system to be restarted in order for the changes to be applied.

GPS Time Synchronization: Select "Sync Local Time" to synchronize the system time to the GPS time. The Status box gives the current status of the GPS.

NOTE: 1PPS from the EASU to the Exciter must be connected to sync to local time.

4.1.12 Exciter Status Bottom Right

4.1.12.1 Status Section

The status section displays current exciter status. Error conditions are displayed in red and warning conditions are displayed in green. Select this area or the System Status Log button to view the status history as shown in Figure 4-13 System Status Log Screen.

As seen in Figure 4-13 System Status Log Screen, several warnings appear. These indicate that the GPS is not time locked. The GPS antenna should be checked for proper view of the sky. At times it will take time for lock to be acquired so you may have to wait for GPS lock.




Figure 4-13: System Status Log Screen

4.2 System Tab Control Buttons

Figure 4-1 shows the GUI main menu System Tab screen: This screen is displayed upon startup. Descriptions of control buttons displayed on the System Tab of this screen are provided in the following subparagraphs.

4.2.1 Shutdown

The Shutdown control screen, Figure 4-14, is used to shutdown the exciter. If power is to be removed, select *Shutdown* and press *OK*. This will halt the OS. Wait until the display indicates *OK* to power down. If the OS is to be restarted, select *OS Restart* and press *OK*. The system will reboot back to the default program. If the application is to be exited and restarted, select *Restart* and press *OK* to exit and rerun the program. If the

application is to be exited and a console session started, select *Console* and press *OK* to exit and start the session.




Figure 4-14:Exciter Shutdown Control Screen

4.2.2 Configuration

The System Configuration button provides access to the system configuration screen, Figure 4-15.

4.2.2.1 View Config

To view the configured rate of the logical channels select *View Config*. When selected, the Channel Configuration screen will be displayed, Figure 4-16.

4.2.2.1.1 Channel Configuration

The Channel Configuration screen is used to view the amount of bandwidth given to each service available; Audio, Station information, or Data. These settings are repeated for all logical channels available:

Channel 0 – P1 Channel 4 -SIS

Channel 2 – P3

4.2.2.1.2 Carrier Configuration

Carrier Configuration displays the Layer 1 current configuration setting.

4.2.2.1.3 Mode

Mode displays the Service Mode.

4.2.2.1.4 Characteristics

The *Characteristics* group box displays the size of the logical channel PDU, the rate at which the PDU is sent, and the bandwidth (or average rate) of the PDU for each logical channel.

4.2.2.1.5 Partitioning

The Partitioning group box displays information pertaining to how each logical channel is partitioned between Main Program Audio (MPA) and Advanced Application Services (AAS).

4.2.2.1.6 Previous

Select Previous Page to scroll through all logical channels.

4.2.2.1.7 Next

Select Next Page to scroll through all logical channels.

4.2.2.2 Save Config

Selecting *Save Config* will create a file of the current system mode configuration files (freq, analog delay...).

4.2.2.3 Configuration Selection

Select the number adjacent to *Enter Item No. for selected configuration*. When selected, the Numeric Keyboard screen, similar to Figure 4-8, is displayed. To change the configuration value, enter the desired configuration value using the number keys. Press *Enter* to establish the new configuration. When a selection is made, the user is prompted to restart the system. See Figure 4-15 for available choices.

4.2.2.4 Restart Options

Selecting *Load Saved Configuration* will use the saved configuration values when restarted.
Selecting *Load Default Configuration* will use the default configuration values when restarted, from this screen only.

4.2.2.5 Restart

Selecting *Restart* will restart the system. Selecting *Close* will exit this window.




Figure 4-15: System Configuration Screens

Channel Configuration

Carrier Configuration **AM HYBRID** Mode **MA1**

Channel 0

Characteristics		Partitioning	
Size (bytes)	466	AAS: Size (bytes)	0
Rate (Hz)	5.41	Bandwidth (kbps)	0.00
Bandwidth (kbps)	20.15	MPS: Size (bytes)	466
		Bandwidth (kbps)	20.15

Channel 2

Characteristics		Partitioning	
Size (bytes)	2997	AAS: Size (bytes)	0
Rate (Hz)	0.68	Bandwidth (kbps)	0.00
Bandwidth (kbps)	16.20	MPS: Size (bytes)	2997
		Bandwidth (kbps)	16.20

OK Prev Next Cancel

Warning: Applet Window

Figure 4-16: Channel Configuration

4.2.3 Versions

When selected a display of the present software/firmware/Motherboard configuration will be shown, Figure 4-17. This information will not be valid until after the system has indicated it is Operational.




Figure 4-17: Versions Screen

To view additional detailed information, select the More button and the display in Figure 4-18.




Figure 4-18: Versions More Screen

4.2.4 Configure Password

When selected the user will be prompted to enter the present password to gain access to the password configure screen, Figure 4-19.

Configure Password

New Password [masked]

Retype Password [masked]

☒ Timeout in seconds 3611

OK Cancel

Figure 4-19: Password Screen

The new password can now be entered. Confirm the new password by entering it again in the Retype Password area.

Timeout in seconds value denotes how long, after entering a valid password, you have unlimited access before you are again prompted to enter the password again. If the checkbox is unchecked the access time has no limit and is valid until changed or the exciter is rebooted.

4.2.5 Command

The System Command screen, Figure 4-20, is displayed when selected.

4.2.5.1 Command/Results

To execute a linux system command (`ls`, `pwd` ...), enter the command here. The results of the command can be displayed immediately by placing a check mark in the *Display Results* box. The results can also go to a file as defined by the file name in the *Results/Output File:* line. To execute the command select *Execute*.

If the Display Results option is selected, Figure 4-22 will now be displayed. Select Close to return to the Exciter Submenu screen.

4.2.5.2 Browse

This button can be selected to choose a file/directory (for execution or results storage). Figure 4-21 will appear. Press *OK* to enter the selection and return to the System Command screen.

4.2.5.3 Common Applications Display Virtual Keyboard

This button, if selected will display a virtual keyboard (Figure 4-23) on the display when the common application is run. This is useful only if a keyboard is not connected to the exciter.




Figure 4-20: System Command Screen

4.2.5.4 Common Applications Xterm

This button, if selected, will display an Xterm Window, (Figure 4-24). The user can now type commands. When done, the user types exit and presses return to close the window and return to the System Command window. In addition to the xterm button, pressing F12 on the keyboard will bring you to an xterm Window. This is the preferred method to access a Linux console. The other way is to press the key combination of CTRL-ALT-F2. However, switching back from this console to the GUI (CTRLALT-F7) may have a detrimental effect on system performance.




Figure 4-21: Browse Screen




Figure 4-22: Command Results Display



Figure 4-23: Virtual Keyboard

```

Executing /etc/profile ...
-- IRSS Make Utility not initialized when running as root
  (/export/dab/SwBase/Bin/irssinit.sh)
[root@sumac tx]# █

```

Figure 4-24: Xterm Window

4.2.5.5 Common Applications gvim



Figure 4-25: Gvim Editor

This button, if selected, will display a Graphical Text Editor (Figure 4-25). The user can now call up a file to edit. When done, select file/exit to return to the System Command screen.




Figure 4-26: Linuxconf Screen

4.2.5.6 Common Applications linuxconf

This button, if selected, will display a graphical linux configuration application (Figure 4-26). The user can now configure the system as desired. When done, select Quit to return to the System Command screen.

4.2.5.7 Common Applications gcalc

This button, if selected, will display a graphical calculator application (Figure 4-27). The calculator is now displayed. Select file/exit to return to the System command screen.



Figure 4-27: Graphical Calculator Screen

4.2.5.8 Common Applications Top

This button, if selected, will display a summary of the processor usage (Figure 4-28). Press Close to finish.




Figure 4-28: Top Display Screen

4.2.5.9 Common Applications ifconfig

This button, if selected, will display a summary of the processor network configuration (Figure 4-29). Press close to quit and return to the System Command window.




Figure 4-29: ifconfig Screen

4.2.5.10 Common Applications setemb

This button, if selected, will set the system to embedded mode. Press close to quit and return to the System Command window. The system is now in Embedded mode, see 1 Startup for embedded mode operation description.




Figure 4-30: Dialog setemb Screen

4.2.5.11 Common Applications setdev

This button, if selected, will set the system to development mode. Press close to quit and return to the System Command window. The system is now in Development mode, see 5.1 Startup for development mode operation description.

4.2.6 GPS Data




Figure 4-31: Dialog setemb Screen

The GPS Data button, when selected, displays the GPS Data screen similar to the one shown in Figure 4-32. This screen displays GPS Version, status, and allows setting of the GPS values.

If the GPS mode is in the **Not Locked mode** (no antenna attached) all the position information can be edited. This information will not be used for transmission unless the system is reset. If the information is changed a warning will be displayed, Figure 4-33, as a reminder.

Figure 4-32: GPS Data Screen




Figure 4-33: System Reset Warning Screen

4.2.6.1 GPS Antenna Delay

This variable is based on GPS cable type and length. Delay values for recommended cable types are listed in Table 4-1.

Table 4-1: GPS Cabling Delays

Cable Type	Delay Value
Belden 9311 (RG-58)	4.36 ns/m (1.33 ns/ft)
Belden 8267 (RG-213)	4.99 ns/m (1.52 ns/ft)
Belden 9104 (RG-59)	4.00 ns/m (1.22 ns/ft)
Belden 9913 (RG-8)	3.90 ns/m (1.19 ns/ft)

To determine the proper delay value, multiply the delay value from Table 4-1 by the length of cable used. For example, if the antenna system includes 50 ft of RG-58 cable, the total cable delay is:
 $50 \text{ ft} \times 1.33 \text{ ns/ft} = 66.5 \text{ ns}$

When entering the data round the value to the nearest nanosecond (ns).

When Antenna Delay is selected, Figure 4-8, is displayed. change the delay value, enter the desired delay value using the number keys. Press *Enter* to establish the new delay value and return to the GPS Data screen.

4.2.7 Local Time

See Section 16 .

4.3 Log Tab Control Buttons

Figure 4-34 shows the GUI main screen Log Tab. Descriptions of control buttons displayed on the Log Tab of this screen are provided in the following subparagraphs.




Figure 4-34: Reference Exciter GUI Interface Log Tab

4.3.1 Levels

Select Levels from the Log Tab main menu, to view and update log level information. The Log Levels screen, Figure 4-35, is displayed. To set the logging level for an individual process, set the Log Level to a value 0 through 7 (0=Off, 7=Max). To set the description associated with the screen logging of each process (not to a file), increase the number under the Verbose Level column (0=Off, 7=Max) to the appropriate level. This sets the logging stored in file /mnt/data/irss.log. This file is archived to a date associated file. For example: /mnt/data/02-19-03/irss02:33:00.log.

4.3.1.1 Previous Page

Select Previous Page to scroll backward through exciter processes.

4.3.1.2 Next Page

Select Next Page to scroll forward through exciter processes.

4.3.1.3 All Log Levels

To set the log level to the same value for all processes, select All Log Levels. Figure 4-36 is displayed. Select the level desired for all processes and press *Close* to enter the new values.

This will log all data with a log level of the selected value or lower.

4.3.1.4 All Verbose Levels

To set the verbose level to the same value for all processes, select All Verbose Levels to display the screen shown in Figure 4-36. Select the desired level and click *Close* to activate the new level.

This will print all data with a verbose level of the selected value or lower.

4.3.1.5 Exclusive Level

Exclusive Level, when selected will only print data that is the same level as the level selected (not lower or higher).

Process Name :	Log Level :	Verbose Level :
adm.x	1	1
log.x	0	1
hdr_dlm.x	1	0
tsm.x	1	0
cmt.x	1	0
ccix.x	1	0
ccexpst.x	1	0
l5mpst.x	1	0
suit.x	1	0

Buttons: Prev, Next, All Log, All Verbose, Close

Figure 4-35: Log Level Screen

Select Level

All processes

☒ 0
 ☐ 1
 ☐ 2
 ☐ 3

☐ 4
 ☐ 5
 ☐ 6
 ☐ 7

☐ Exclusive Level

Close

Figure 4-36: Select Level Screen

4.3.2 Parameters

Select Parameters from the Log main menu. The Log Parameters screen (Figure 4-37) is displayed. This screen will display the present logging utilization and allow for the setting of warning parameters.

4.3.2.1 Warning Message Rate

When Warning Message Rate is selected, the Numeric Keyboard screen is displayed (Figure 4-8). To set how often the user is warned that the maximum log rates have been exceeded; enter the desired time in seconds. Press enter to use the new value and return to the Log Parameters screen.

4.3.2.2 Window Size (sec):

When Window Size is selected, the Numeric Keyboard screen is displayed (Figure 4-8). To set the duration over which the logging rate is calculated, enter the desired time in seconds. Press enter to use the new value and return to the Log Parameters screen.

4.3.2.3 ASCII Log Rate (bytes/sec):

ASCII Log Rate displays the instantaneous amount of ASCII logging.

4.3.2.4 ASCII Log Utilization:

ASCII Log Utilization displays the instantaneous amount of ASCII logging represented as a percentage of the maximum rate.

4.3.2.5 ASCII Log Max Rate:

When Max ASCII Log Rate is selected, the Numeric Keyboard screen is displayed (Figure 4-8). To set the log rate for which, if exceeded, a warning will be issued, enter the desired rate. Press enter to use the new value and return to the Log Parameters screen.

4.3.2.6 Binary Log Rate (bytes/sec):

Binary Log Rate displays the instantaneous amount of Binary logging.

4.3.2.7 Binary Log Utilization:

Binary Log Utilization displays the instantaneous amount of Binary logging represented as a percentage of the Maximum rate.


4.3.2.8 Binary Log Max Rate:

When Max Binary Log Rate is selected, the Numeric Keyboard screen is displayed (Figure 4-8). To set the log rate for which, if exceeded, a warning will be issued, enter the desired rate. Press enter to use the new value and return to the Log Parameters screen.

4.3.2.9 Start Archive

When *Start Archive* is selected, all log files in the /mnt/data path along with any core files in the bin/tx path will be collected and placed in the specified archived file.





The screenshot shows a 'Log Parameters' window with several sections:

- Warning Message Rate:** A text box containing '5.0'.
- Window Size (sec):** A text box containing '2'.
- ASCII Log:**
 - Rate (bytes/sec):** A text box containing '223'.
 - Max Rate:** A text box containing '20000'.
 - Utilization:** A progress bar showing '1 %'.
- Binary Log:**
 - Rate (bytes/sec):** A text box containing '0'.
 - Max Rate:** A text box containing '10000'.
 - Utilization:** A progress bar showing '0 %'.
- Archive:**
 - A 'Start Archive' button.
 - A progress bar that is partially filled with blue.
 - A text box containing 'NO ARCHIVE FILE'.
- Buttons:** 'Reset' and 'X Close' buttons at the bottom.

Figure 4-37: Log Parameters Screen

4.3.3 System Status

See paragraph 4.1.12.

4.4 Platform Tab Control Buttons

Figure 4-38 shows the GUI main screen Platform Tab. Descriptions of control buttons displayed on the Platform Tab of this screen are provided in the following subparagraphs.




Figure 4-38: Reference Exciter GUI Interface Platform Tab

4.4.1 Platform Configure

See paragraph 4.1.1.

4.4.2 Link Status

The Link Status window provides status for all active TCP/UDPLink connections, Figure 4-39.

Each Link (e.g. I2E, E2X) window is divided into 2 panels: a send panel and a receive panel. In both cases, statistics are displayed for all the messages received on the indicated connection. The connection being examined is displayed in the upper left corner. In Figure 4-39 it is the I2E link. In addition, an error count for a number of different types of standard failures is also displayed.

Each link has its own window. The user can scroll through each link by pressing the "Prev" or "Next" button. The number and types of windows available will depend on the platform type. For example, the E2X window is not displayed on an Exciter platform because it does not exist.

Figure 4-40 shows the GUI main screen Station Tab. Descriptions of control buttons displayed on the Station Tab of this screen are provided in the following subparagraphs.

Link Status

Importer to Exporter (I2E) Link

Protocol **TCP** (Disconnected)

Send		Receive	
Total Message Counts		Total Message Counts	
Sent	0	Received	0
Passed	0	Passed	0
Failed	0	Failed	0
Error Message Counts		Error Message Counts	
Invalid Protocol	0	Invalid Protocol	0
Version Mismatch	0	Version Mismatch	0
Invalid CRC	0	Invalid CRC	0
Sequence Mismatch	0	Sequence Mismatch	0
Source Unknown	0	Source Unknown	0
Destination Unknown	0	Destination Unknown	0

Reset < Prev Next > X Close

Figure 4-39: I2E Activity Monitor Screen

4.5 Station Tab Control Buttons

Exciter **HD** **930** **AM** **OPERATIONAL**
NO ALARM

©2010 iBiquity Digital Corp. Version 4.3.2p1

<p>Audio Bypass</p> <p>None</p> <p>Digital Carrier Control</p> <p><input checked="" type="radio"/> On <input type="radio"/> Off</p> <p>Analog Modulation</p> <p><input checked="" type="radio"/> On <input type="radio"/> Off</p> <p>Layer 1 Service Mode</p> <p>MA1</p>	Station Interface	SYSTEM
	Station Information Schedule	LOG
	Station Information	PLATFORM
	Station Default PAD	STATION
	Station Program Control	AUDIO
		SIGNAL
		TEST
	UTILITY	

Thu Sep 15 15:44:51 2011 **HD**

Figure 4-40: Reference Exciter GUI Interface Station Tab

4.5.1 Station Interface

Select Station Interface, to display the Station Interface screen, Figure 4-41.

The current state of all 16 inputs is shown in the left column. For inputs 1 through 14, a high-to-low transition will initiate the corresponding action. For inputs 15 and 16, the input must be held low for at least 5 seconds, then, on the ensuing positive edge, the corresponding action is executed. The current status is shown in the right-hand column. To clear any present alarms select *Clear State Alarm*. To set the Non-operational state back to Operational select *Clear State Non-operational*. This will place the system back into a operational state until the next error is encountered.

When *Start Test* is selected, the outputs will all be set to a low state, and a high state will be walked through spending a second in each state. The inputs will still be continuously monitored. When *Stop Test* is selected, the outputs will return to the values stored prior to entering test mode. When *Enable Watchdog* is selected, the Watchdog timer on the Station Interface Card (SIC) will be enabled. When enabled, the SIC will monitor the serial port, if there is no activity for 1 second the host processor is assumed to be locked up. The Audio bypass relays will be set to Bypass, the system operational relay will be opened and the exciter will be rebooted.

Press *Close* to return to the Main Menu.

The Station Interface screen displays a table of 16 inputs and 16 outputs, along with control buttons for Test Interface, Clear State, and Watchdog.

State	Inputs	State	Outputs
1 High	1: Digital Carrier On	1 On	1: Digital Carrier On/Off Status
1 High	2: Digital Carrier Off	1 Done	2: Audio Ramp Up/Down Status
1 High	3: Audio Ramp Up To Delay	1 Done	3: Audio Delay In/Decrease Status
1 High	4: Audio Ramp Up From Delay	0 Normal	4: Audio-A Bypass Status
1 High	5: Audio Delay Increase	0 Normal	5: Audio-B Bypass Status
1 High	6: Audio Delay Decrease	1 Day	6: Day/Night Status
1 High	7: Audio-A Bypass On	0 ---	7: System Shutdown Status
1 High	8: Audio-A Bypass Off	1 OK	8: System Operational Status
1 High	9: Audio-B Bypass On	0 OK	9: System Alarm Status
1 High	10: Audio-B Bypass Off	0	10:
1 High	11: Day	0	11:
1 High	12: Night	0	12:
1 High	13:	0 Normal	13: Audio-A Bypass Status (Relay)
1 High	14: System Shutdown	0 Normal	14: Audio-B Bypass Status (Relay)
1 High	15: System Power On/Off Toggle	1	15:
1 High	16: System Reset	0 OK	16: System Operational Status (Relay)

Below the table are three control sections:


- Test Interface:** Test State **Stopped**, with **Start** and **Stop** buttons.
- Clear State:** **Alarm** and **Non-Operational** buttons.
- Watchdog:** ☐ **Enable** checkbox.

A **Close** button is located at the bottom center.

Figure 4-41: Station Interface Display Screen

4.5.2 Station Information Schedule

The Station Information Schedule, Figure 4-42, is displayed when selected from the main menu. Select the block to be changed and the payload selection menu will be displayed, Figure 4-43. Select the payload option desired, and press *OK* to enter the new settings and return to the main menu.



The screenshot shows a software window titled "Station Information Schedule". It contains a table with two columns: "Payload 1" and "Payload 2". The rows are indexed by "Block #". The table is as follows:

Block #	Payload 1	Payload 2
0	CALLSIGN STANDARD	STATION ID
1	SLOGAN STANDARD	
2	CALLSIGN STANDARD	STATION ID
3	SLOGAN STANDARD	
4	SLOGAN STANDARD	
5	CALLSIGN STANDARD	STATION LOCATION
6	CALLSIGN STANDARD	STATION ID
7	CALLSIGN STANDARD	STATION LOCATION

Below the table are four buttons: "OK" (with a hand icon), "Prev" (with a left arrow), "Next" (with a right arrow), and "Cancel" (with a red X icon).

Figure 4-42: Station Information Schedule Screen

Care must be taken when selecting payload options as some options are not compatible with other options. For example Slogan Universal requires both payloads, so Payload 2 must be left blank. If an incompatible payload is selected a warning message similar to Figure 4-44 will be displayed.



Figure 4-43: Station Information Payload Selection




Figure 4-44: Incompatible payload option warning message

4.5.3 Station Information

See paragraph 4.1.2.

4.5.4 Station Default PAD

The Station's default PAD information, Figure 4-45, is displayed when selected from the Station main menu. This menu has four tabs: General, Comment, Commercial, and Last Message Sent. Each tab is described in turn.

4.5.4.1 General

Use this tab shown in Figure 4-45 to enter the Title, Artist, Album, and Genre information by selecting the desired field and using the alphanumeric keyboard similar to the one in Figure 4-6. To include this information as part of the PAD message make sure the "Enable" box is checked. Clearing the Enable box will exclude this information from being sent.

Note: Even though Genre is a text field, the user should select one of the types defined in the IDS standard, if possible.

Station Default PAD

General Comment Commercial Last Message Sent

☒ Enable

Title **HD Radio...www.HD-Radio.com**

Artist

Album


Genre

Send Update Cancel

Figure 4-45: Station Default PAD (General Tab)

4.5.4.2 Comment

Use this tab shown in Figure 4-46 to enter the Comment Title and Comment Description information by selecting the desired field and using the alphanumeric keyboard similar to the one in Figure 4-6. To include this information as part of the PAD message make sure the “Enable” box is checked. Clearing the Enable box will exclude this information from being sent.




The dialog box is titled "Station Default PAD". It has four tabs: "General", "Comment", "Commercial", and "Last Message Sent". The "Comment" tab is selected. Inside the dialog, there is an "Enable" checkbox which is unchecked. Below it, the "Title" field contains the text "IID Radio 'Rocks'" and the "Description" field contains the text "Steve is the Man!!!!". At the bottom of the dialog are three buttons: "Send", "Update", and "Cancel".

Figure 4-46: Station Default PAD (Comment Tab)

4.5.4.3 Commercial

Use this tab shown in Figure 4-47 to enter the Commercial information by selecting the desired field and using the alphanumeric keyboard similar to the one in Figure 4-6. To include this information as part of the PAD message make sure the "Enable" box is checked. Clearing the Enable box will exclude this information from being sent.



The dialog box is titled "Station Default PAD". It has four tabs: "General", "Comment", "Commercial", and "Last Message Sent". The "Commercial" tab is selected. Inside the dialog, there is an "Enable" checkbox which is unchecked. Below it, the "Price" field contains "\$100,000,000", the "Contact URL" field contains "www.HD-Radio.com", the "Valid Until" field contains "Dec 31 2017", the "Received As" field contains "00 Other", the "Name of Seller" field contains "Steve", and the "Description" field contains "Make Steve Rich!!!!". At the bottom of the dialog are three buttons: "Send", "Update", and "Cancel".

Figure 4-47: Station Default PAD (Commercial Tab)

4.5.4.4 Last Message Sent

Use this tab, shown in Figure 4-48, to view the last message sent in ID3 format.




Figure 4-48: Station Default PAD (Last Message Sent Tab)

In addition to the four tabs, the Station Default PAD screen also has four buttons: Send, Update, Advanced, and Cancel.

4.5.4.5 Send

When pressed, the current information in the General, Comment and Commercial screens, if enabled, will be queued for transmission as indicated by the screen shown in Figure 4-49.



Figure 4-49: Information Sent acknowledgement message

4.5.4.6 Update

When pressed, the current information in the General, Comment, and Commercial screens is saved as part of the default configuration for that Service Mode as indicated by the acknowledgement message shown in Figure 4-50.



Figure 4-50: PAD Configuration update acknowledgement

4.5.4.7 Cancel

Use Cancel to return to the main Station screen.

4.5.5 Station Program Control

The station's programming genre and program audio processing selection, Figure 4-51, is displayed when the Select Station Program Control is selected.



Figure 4-51: Station Program Control screen

This "Program Type" allows the user to send a genre type transmitted as part of the SIS message and embedded in the main program audio bit-stream. To change the genre, use the pull down menu and select the genre type most appropriate. The "Program Audio Processing" indicates to the receiver what, if any, additional audio processing is being performed on the main program audio. Currently the Program Audio Processing is a number from 0-31 and it will be up to the audio processing constituents to coordinate the assignments of numbers.

4.6 Audio Tab Control Buttons

Figure 4-52 shows the GUI main screen Audio Tab. Descriptions of control buttons displayed on the Audio Tab of this screen are provided in the following subparagraphs.




Figure 4-52: Reference Exciter GUI Interface Audio Tab

This button, if selected, will display the Analog Audio Diversity Screen, Figure 4-54.

4.6.1 Audio Levels

This button, if selected, will display a dynamic Audio Monitor, Figure 4-53.

4.6.1.1 Range (dB)

Select this option to change the Minimum value (left most value of audio bars) of the audio Bar graph, the Numeric Keyboard (Figure 4-8) is displayed. To change the Range, in dB down from Full Scale, enter the new value using the number keys.

4.6.1.2 Average (sec)

Select this option to change the time over which the average of audio power is taken to be displayed as the green portion of the audio Bar graph. The Numeric Keyboard (Figure 4-8) is displayed. To change the average time, enter the new value using the number keys.

NOTE: If this number is larger than the peak and/or peak hold numbers those values will be changed to equal the Average time.

4.6.1.3 Peak (sec)

Select this option to change the time over which the peak of audio power is taken to be displayed as the Yellow portion of the audio Bar graph. The Numeric Keyboard (Figure 4-8) is displayed. To change the Peak time, enter the new value using the number keys.

NOTE: If this number is larger than the peak hold number the Peak Hold value will be changed to equal the Peak time.

4.6.1.4 Peak Hold (sec)

Select this option to change the time over which the peak of audio power is taken to be displayed as the Red portion of the audio Bar graph. The Numeric Keyboard (Figure 4-8) is displayed. To change the Peak Hold time, enter the new value using the number keys.




Figure 4-53: Audio Levels Screen

4.6.2 Analog Audio Diversity




Figure 4-54: Analog Diversity Delay Screen

4.6.2.1 Delay

The Delay indicator displays the number of 44.1-kHz audio samples (22.67 us/sample) analog audio is to be delayed if the Analog Audio Diversity Status is 100%.

The Delay field, when selected, displays the Numeric Keyboard screen (similar Figure 4-8). To change the delay value, enter the desired Delay Value using the number keys. Press *Enter* to establish the new delay value and return to the Analog Audio Diversity screen.

4.6.2.2 Increment

The Increment indicator displays the number of 44.1-kHz audio samples the delay value is changed when the up or down arrow buttons are selected.

The Increment field, when selected, displays the Numeric Keyboard screen (similar to Figure 4-8). To change the increment value, enter the desired increment value using the number keys. Press *Enter* to establish the new increment value and return to the Analog Audio Diversity screen.

4.6.2.3 Delay in seconds

The Delay-in-seconds indicator displays the total analog audio delay when the Audio Diversity Delay Status is 100%. The displayed value is only accurate to +/-50 milliseconds.

4.6.2.4 Current Delay in seconds

The Current Delay-in-seconds indicator displays the current analog audio delay in seconds. Depending on the delay and the rate, the current value should either be equal to or converging to the delay value or converging to 0. The displayed value is only accurate to +/-50 milliseconds.

4.6.2.5 Automatic Adjustment Ramp Up

Ramp Up, when selected, begins a delay increase using the rate value from 0 to the desired delay value.

4.6.2.6 Automatic Adjustment Ramp Down

Ramp Down, when selected, begins a delay decrease using the Rate value from the present delay value to 0.

4.6.2.7 Rate

The Rate indicator displays the rate at which the total delay can be changed. If the rate is 0 when the delay is changed, it will be executed immediately. If the rate is 100 and the delay is changed, that change will slowly take effect: for every 100 audio samples, 1 extra sample is inserted or extracted. The higher the rate, the longer it will take to achieve the final value.

The Rate field, when selected, brings up the Numeric Keyboard screen (similar to Figure 4-8). To change the Rate value, enter the desired rate using the number keys. Press *Enter* to establish the new Rate and return to the Analog Audio Diversity screen.

4.6.2.8 Audio Monitor

The Audio Monitor indicates/controls the audio stream present at the Exciter Monitor output. The options are:

- Delayed Analog Audio is (same as the analog Audio out) the diversity delayed input analog audio.
- Analog Audio is the input analog audio.
- Digital Audio is the input digital audio.
- AM Mono Audio is the monophonic input analog audio. Any internal band-limiting filters have not yet been applied.
- Receiver Monitor Audio is the digital audio encoded then decoded.
- Tone Monitor places a 1-kHz full-scale sine wave on the monitor output.

4.6.2.9 Invert Digital Audio Phase

When this box is checked, the phase of the digital audio stream is inverted.

4.6.2.10 Audio Diversity Delay Status

The Audio Diversity Delay Status indicator displays the percentage of current diversity delay.

4.6.2.11 Audio Card 0 Input Level

The Audio Card 0 Input Level indicator displays activity on the audio card 0 input path.

4.6.2.12 Audio Card 0 Output Level

The Audio Card 0 Output Level indicator displays activity on the audio card 0 output path.

4.6.2.13 Audio Card 1 Input Level

The Audio Card 1 Input Level indicator displays activity on the audio card 1 input path.

4.6.2.14 Audio Card 1 Output Level

The Audio Card 1 Output Level indicator displays activity on the audio card 1 output path.



4.6.3 Audio Bypass

4.6.3.1 See Section 4.1.7 .

4.6.4 Analog Audio Bandwidth

The Analog Audio Bandwidth indicator displays the bandwidth limit of the transmitted analog audio as 5kHz, 8-kHz, 5 kHz External, or 5-8 kHz External. When selected the Analog Audio Bandwidth screen, Figure 4-55 is displayed. The state is changed by selecting the desired radio button. When complete select *Ok* to activate the new setting and return to the main menu.



Figure 4-55: Analog Audio Bandwidth Control

Note: The External options assume the appropriate filtering has been applied prior to input into the exciter.

4.6.5 Audio Blend Control

The Exciter can transmit a control bit to the receiver that indicates not to blend between analog and digital. This could be used in cases of different audio content or non-time alignment. When this bit is set it is up to the receiver to determine which audio stream is used. Figure 4-56 shows the selections possible.

If *Enable Audio Blending* is selected, blending will occur regardless of the mode or the state of the diversity delay. If *Enable Audio Blending, only when audio alignment is completed* is selected, blending will only be enabled if the diversity delay is completely ramped up. Blending will automatically be disabled when diversity delay is either being applied (Section 4.6.2.5) or removed (Section 4.6.2.6) or if the diversity delay is completely ramped down. *Disable Audio Blending* allows the blending to be disabled for certain service modes. *Disable Audio Blending, But Allow Independent Selection* is used when different program material is being transmitted on the digital or analog channels.



Figure 4-56: Audio Blend Control Screen

4.6.6 Audio Level Control

The exciter can transmit control information to the receiver to indicate adjustments between the analog and digital audio using the Audio Level Control screen shown in Figure 4-57. When selected a numeric keyboard screen similar to Figure 4-8 is displayed. To change the recommended level adjustment, enter the desired value using the number keys. Press "Enter" to establish the new value and return to the Audio screen.




Figure 4-57: Audio Level Control Screen

4.6.7 Digital Audio Configuration

The exciter can set the core audio mode for the MPS audio stream using the Digital Audio Configuration screen shown in Figure 4-58. The setting selected is normally based on the bit rate of the MPS audio stream. For bit rates less than 16 kbps the Monophonic setting is recommended, for bit rates greater than 16 kbps and less than 32 kbps the Parametric Stereo selection is recommended and for bit rates greater than 32 kbps the Stereo selection is recommended.

Figure 4-59 shows the GUI main screen Signal Tab. Descriptions of control buttons displayed on the Signal Tab of this screen are provided in the following subparagraphs.




Figure 4-58: Digital Audio Configuration

4.7 Signal Tab Control Buttons




Figure 4-59: Reference Exciter GUI Interface Signal Tab

4.7.1 Frequency

See paragraph 4.1.3.

4.7.2 Layer 1 Service Mode

See paragraph 4.1.10.

4.7.3 Signal Configuration

Figure 4-60 shows signal configuration screen. Descriptions of control button and value selections displayed on this screen are provided in the following subparagraphs.




Figure 4-60: Signal Configuration Window

4.7.3.1 Digital Carrier

See paragraph 4.1.8.

4.7.3.2 Analog Modulation

See paragraph 4.1.9.

4.7.3.3 Enhanced Carrier Power Level

The Enhanced Carrier Power Level group box displays the level of the enhanced carriers as Normal, High (MA1 only) or Off. When in the Normal state the secondary and tertiary portion of the IBOC waveform are set to -44dBc and -50dBc respectively for MA1 and -30dBc for both in MA3. When in the high state, the levels of the secondary and tertiary sidebands portion of the IBOC waveform are increased by 6 dB relative to the Normal setting. When in the Off state the secondary and tertiary portions of the IBOC waveform are turned off. The Enhanced Carrier Power Level selection determines what PIDS High Power selections are available and the power levels that correspond to the High Power PIDS states. See section

4.7.3.4 PIDS High Power

The selection and meaning of the High Power PIDS states depend on the Enhanced Carrier Power Level selection as shown in Table 4-2 and Table 4-3.

Table 4-2: PIDS Carriers Power Levels Mode MA1

Selected Enhanced Carrier Power Level	Selected High Power PIDS	Inner PIDS Carriers (between Secondary/Tertiary portion of IBOC waveform)	Outer PIDS (between Primary/Secondary portion of IBOC waveform)
Normal	Off	43 dB below unmodulated analog carrier	13 dB below Primary Carriers Level
Normal	On	43 dB below unmodulated analog carrier	Same as Primary Carriers Level
High	Off	37 dB below unmodulated analog carrier	7 dB below Primary Carriers Level
High	On	37 dB below unmodulated analog carrier	Same as Primary Carriers Level
Off	On	Carriers are turned off	Same as Primary Carriers Level

Table 4-3: PIDS Carriers Power Level Mode MA3

Selected Enhanced Carrier Power Level	Selected High Power PIDS	PIDS Carriers
Normal	Off	15 dB below Primary Carrier Power Level
Normal	On	Same as Primary Carriers Level
Off	Off	15 dB below Primary Carrier Power Level
Off	On	Same as Primary Carriers Level



4.7.3.5 I/Q Scale Factor

I/Q Scale Factor sets the level of the composite magnitude signal prior to the last D/A (nominally 12000 for MA1 and 6000 for MA3). Exercise caution when adjusting this value. This, in combination with Analog gain and Magnitude DC level, can cause D/A overflow resulting in spectral distortion.

Selecting I/Q Scale Factor, Figure 4-59, displays the Numeric Keyboard screen, similar to Figure 4-8. To change the I/Q Scale Factor enter the desired value using the number keys. Press *Enter* to activate the new I/Q Scale Factor and return to the Signal Configuration Menu.

4.7.3.6 Magnitude Channel DC Offset

Magnitude Channel DC Offset adjusts the desired Magnitude channel DC level. This is the amount of modification to the normal value 1. When set to 0, the Magnitude DC level is 1.

Selecting Magnitude Channel DC Offset, Figure 4-59, displays the Numeric Keyboard screen, similar to Figure 4-8. To change the Magnitude Channel DC Offset, enter the desired Magnitude Channel DC Offset using the number keys. Press *Enter* to execute and return to the Signal Configuration menu.

4.7.3.7 Analog Gain

Analog Gain allows you to adjust the modulation of the analog signal. Care should be taken when adjusting this value to ensure the analog audio remains within the FCC limits of +125%, -99% modulation. In addition this, in combination with I/Q Scale Factor and Magnitude Channel DC offset, can cause D/A overflows resulting in spectral distortion.

Analog Gain, when selected, will bring up the Numeric Keyboard screen, similar to Figure 4-8. To change the Analog Gain, enter the desired Analog Gain using the number keys. Press *Enter* to activate the new Analog Gain and return to the Signal Configuration menu.

4.7.3.8 Magnitude/Phase Delay

Magnitude/Phase Delay provides adjustment of the delay between the Magnitude and Phase signals. The initial Magnitude/Phase Delay should be set to 13445 and should be advanced in increments of 16 (a single unit is 84ns).

When either Value or Increment is selected a numeric keyboard similar to Figure 4-8 will be displayed. Use this keyboard to change the value of the "Value" or increment to the desired value.

The up/down buttons can be used to increase/decrease the values of "Value" or "Increment." Increment is increased/decreased by one where "Value" is increased/decreased by "Increment."

4.7.3.9 Primary Sideband Power Level

The Primary Sideband Power Level group allows the primary upper and lower (Core) carriers to be scaled up or down.

NOTE: Care should be taken when adjusting these parameters. Increasing these carrier levels will increase the adjacent channel interference and decreasing the carrier level will decrease the stations coverage area.

When Lower or Upper Sideband Scaling Number is selected, the numeric keyboard, Figure 4-8, is displayed. To change the Sideband Scaling enter the desired Sideband Scaling in dB using the number keys. Press *Enter* to select the new Sideband Scaling and return to the Signal Configuration menu.

To change the Sideband Scaling value in 1 dB increments use the up/down arrow buttons.

To change the Sideband Scaling value in other dB increments select the scaling Increment, the numeric keyboard, similar to Figure 4-8, is displayed. To change the Scaling increment, enter the desired Scaling

increment in dB using the number keys. The up/down arrows will now change the sideband using the new increment value.

4.7.3.10 Presets

The 5 buttons at the bottom of the Signal Configuration menu allow for the management of the available preset configurations. Once the desired signal configurations are set, press *Save* and a dialog box similar to Figure 4-61 is displayed. Select the desired preset, enter the desired name and hit OK.




Figure 4-61: Save Signal Preset Dialog box

To view the setting for all presets select *View* and a display box similar to Figure 4-62 will be displayed.




Figure 4-62: Signal Preset View Window

To load a preset simply press *Load* and a dialog box similar to Figure 4-62 will be displayed. Select the desired preset and hit OK to return to the Signal Configuration menu. To restore the signal configurations to the factory default parameters select *Restore*. Finally to return to the main menu press *Close*.

4.8 Test Tab Control Buttons

Figure 4-63 shows the GUI main screen Test Tab. Descriptions of control buttons displayed on the Test Tab of this screen are provided in the following subparagraphs.

NOTE: All functions under the Test Tab REQUIRE a password to be accessed.




Figure 4-63: Reference Exciter GUI Interface Test Tab

4.8.1 Bit Error Rate Mode

The Bit Error Rate (BER) mode control selects either normal audio mode or Layer 1 BER mode (no digital audio) (Figure 4-64).




Figure 4-64: Bit Error Rate Mode Screen

BER Mode = 1 sets the exciter to transmit a bit pattern that can be checked at the receiver Modem output. Once in BER Mode the AM Layer 1 Service mode can be selected. To exit BER Mode, return the Layer 1 service mode to MA1 and select BER Mode Off.

4.8.2 Single Subcarrier Mode

The Single Subcarrier Screen, Figure 4-65, is displayed when selected from the GUI Interface menu, Figure 4-63. This screen provides digital carrier selection for test purposes.

Select hybrid Subcarrier mode for MA1 and all digital for MA3.

The subcarrier number refers to the carrier that will be transmitted. The value -81 corresponds to the lowest frequency subcarrier and increments to +81 for MA1 and -53 to 53 for MA3. When Subcarrier Number is selected, Figure 4-65, the numeric keyboard, Figure 4-8, is displayed. To change the Subcarrier Number enter the desired Subcarrier Number using the number keys. Press *Enter* to select the new Subcarrier Number and return to the main menu.




Figure 4-65: Single Subcarrier Mode Screen

4.8.3 Test Vector Capture

The Test Vector Capture screen, Figure 4-66, is displayed when selected from the GUI Test Menu. This screen provides the ability to capture IF modulated IQ samples over a number of L1 Frame times. This functionality requires specialized knowledge of other system configuration elements which must be correctly set and is use for iBiquity test purposes. Without the correct configuration no data can be captured and this screen has no effect.




Figure 4-66:Test Vector Capture Screen

4.9 Utility Tab Control Buttons

4.9.1 Screen Resize

The Screen Resize window allows the user to change the dimensions of the display, Figure 4-67.

4.9.1.1 Width Value

This displays the present value of the screen width. This can be raised or lowered using the + or – buttons.

4.9.1.2 Height Value

This displays the present value of the screen height. This can be raised or lowered using the + or – buttons.

4.9.1.3 Test

When selected, Test will display a test screen, Figure 4-68. Verify that the entire border is visible and select OK when complete.




Figure 4-67: Screen Resize Screen




Figure 4-68: Screen Size Test Screen

4.9.1.4 Default Size

When selected, both the height and the width values will be reset to default settings.

4.9.1.5 Apply

When selected, the user will be prompted to reboot the system to make use of the new screen settings, Figure 4-69. Selecting Yes will proceed with the reboot and NO will cancel the action and return to the Exciter Main screen.



Figure 4-69: Apply Reboot Screen

4.9.1.6 Cancel

When selected, the user will be returned to the Exciter Main screen.

4.9.2 Fonts

This button, if selected, will display a System Fonts screen, Figure 4-70.



Figure 4-70: System Fonts Screen

The upper section if selected allows the user to select the font used on all small data presentation areas. The lower section if selected allows the user to select the font used on all large data presentation areas.




Figure 4-71: System Pick-a-Fonts Screen

4.9.3 Virtual Chat

The Virtual Chat Screen, Figure 4-72, allows direct communication between 2 users logged in to the same exciter. If a user is at the exciter and a second user has logged in remotely, using Virtual Chat they can communicate directly. By entering the information to be sent in the bottom window and pressing Send the message will be relayed to the other user. All communications will be displayed in the upper window.




Figure 4-72: Virtual Chat Screen

4.9.4 Activity Monitor


See paragraph 4.1.

4.9.5 Up Time

When selected, the screen shown in Figure 4-73 displays information about the length of time the exciter has been operational. Two columns are displayed: Calendar Time and Elapsed Time. Calendar Time represents the date and time the last event occurred. The Elapsed Time displays the total time in years, days, minutes, and seconds from the last event.

The events displayed are:

1. OS Start – The last time the OS was restarted.
2. System Start – The last time the application was started.
3. Last System Shut-down – The last time the system was shutdown.
4. Last System Error – The last time a warning or system error occurred.



The image shows a software window titled "Up Time". Inside the window, there is a table with two columns: "Calendar Time" and "Elapsed Time". The table lists five events: OS Start, System Start, Last System Shutdown, Last System Error, and Last System Warning. The "Calendar Time" column shows dates and times, while the "Elapsed Time" column shows durations in years, days, minutes, and seconds. A "Close" button is located at the bottom of the window.

	Calendar Time	Elapsed Time
OS Start	Jul 14, 2004 15:43:28	0000 y, 006 d, 20:07:20
System Start	Jul 16, 2004 13:13:14	0000 y, 004 d, 22:37:34
Last System Shutdown	Jul 16, 2004 13:12:52	0000 y, 004 d, 22:37:56
Last System Error	none	none
Last System Warning	Jul 16, 2004 13:13:46	0000 y, 004 d, 22:37:02

X Close

Figure 4-73: Up Time Information Screen

5 Operating Procedures

This section provides ASi 10 operating procedures.

5.1 Startup

The ASi 10 will start up on its own after power is applied and the power switch is on.

NOTE: Be sure to have the ASi 10 Line Voltage switch in the correct location for the AC voltage to be applied. Damage can result if the wrong voltage is used!

5.2 Audio Diversity Blend Delay Adjustment

On a calibrated receiver, set the Audio Mode to Split Analog/Digital. If a calibrated receiver is not available, use a standard HD radio receiver and switch between Analog and Digital to monitor the transmission time difference between the two.

On the ASi 10:

1. Select Analog Audio Diversity, from the Main Screen Audio Tab.
2. Set Delay to 367500. This is the delay that synchronizes audio in a BE system with no processors using the IBequity reference receiver and no processing delay. Your system may require a different delay when measured using a commercial receiver.
3. Set Increment to 1000.
4. Set Rate to 0.
5. Monitor the audio from the receiver while using the up/down arrow keys until proper alignment of the digital and analog audio streams is achieved. They are aligned when you can no longer notice a time delay difference between analog and digital receive modes. Close all adjustment windows and the values will be saved for subsequent startup.

5.3 Shutdown Procedure

1. Select Shutdown from the Main Screen System Tab. You should then see.
2. If power is to be removed, select Shutdown and press OK. This will halt the OS. Wait until the display indicates OK to power down.
3. If the OS is to be restarted, select OS Restart and press OK. The system will reboot back to the default program.
4. If the application is to be exited and restarted, select Restart and press OK to exit and rerun the program.

5.4 Magnitude/Phase Delay Adjustment

5.4.1 AM Phase Delay Adjustment

The IBOC system is aligned for the correct signal spectrum using the AM phase delay adjustment and an amplitude adjustment. The following text presents the information to adjust the AM phase delay.

Select Magnitude/Phase Delay. The Magnitude Phase Delay screen, Figure 5-1, is displayed.



Selected	Magnitude/Phase Delay	Value	Increment
<input checked="" type="radio"/>	Day	10859	1
<input type="radio"/>	Night	10859	1
<input type="radio"/>	Description	1	1
<input type="radio"/>	Description	1	1
<input type="radio"/>	Description	1	1
<input type="radio"/>	Description	1	1
<input type="radio"/>	Description	1	1
<input type="radio"/>	Description	1	1

Figure 5-1: Magnitude/Phase Delay Screen

Select the first area under the value column to modify for the initial value (10875 is a good starting point). Select the first area under the increment column (16 is a good starting point). This increment has an 84ns resolution.

Select the box under the Activate column and the adjustment screen, Figure 5-2, is displayed:

Day	10859	1		
-----	-------	---	--	--


Figure 5-2: Delay Adjustment Screen

5.5 IBOC System Alignment


The IBOC system is aligned for the correct signal spectrum using the AM phase delay adjustment and an amplitude adjustment. To align the system perform the following:

1. Locate a 2-channel oscilloscope.
2. Connect a cable from the transmitter sample port to channel 1 on the oscilloscope.
3. Connect a cable from the AM OUT on the ASi to channel 2 on the oscilloscope.
4. The waveforms will appear as random amplitude variations of the carrier with widely varying peaks (refer to Figure 5-3). Sync one channel of the oscilloscope with the maximum signal level. The two channels will appear to reach peak and minimum levels at the same instance in time. The waveforms shown include only one sample sweep such as from a digital storage scope. An analog oscilloscope display will contain many seemingly random sweeps and must be viewed carefully.
5. To amplitude align the ASi and the transmitter, adjust the output level control in the ASi until the amplitude level is identical for both waveforms (refer to Figure 5-4).
6. To time align the ASi and the transmitter, refer to AM Phase Delay Adjustment in the preceding text and adjust the delay until the delay (peaks and valleys of the AM signal) are aligned in time (refer to Figure 5-5).
7. Once the waveforms are amplitude and time aligned, the receiver will lock to the digital mode. This alignment also provides for optimum spectral performance (refer to Figure 5-6).







Transmitter Waveform



ASi AM OUT Waveform - Misaligned Time Waveforms




Transmitter Waveform




ASi AM OUT Waveform

Misaligned AM Amplitude Waveforms

Figure 5-3: Misaligned Transmitter/ASi Waveforms




Transmitter Waveform




AM OUT Waveform from ASi

Figure 5-4: Aligned AM Amplitude Transmitter/ASi Waveforms



Transmitter Waveform



AM OUT Waveform From ASi

Figure 5-5: Time Aligned Transmitter/ASi Waveforms

Date: 02-04-00 Time: 15:29




Figure 5-6: Typical AM aligned spectrum

5.6 Remote GUI Control

When the ASi 10 operating system is running, control can be remotely established using a standard web browser such as Internet Explorer. A network connection to the ASi must be established either by Ethernet or modem (see Paragraph 5.7).

Network setup for the ASi 10

Using an external keyboard is recommended.

1. Press the Command button on the Main ASi 10 screen. The following screen will open after typing in the Password.




Figure 5-7: System Command window

2. Press linuxconf. The following screen will open.



Figure 5-8 linuxconf Main Window

3. Press Enter on the keyboard. The following screen will open.




Figure 5-9 linuxconf Networking Window

4. Press Enter on the keyboard. The following screen will open




Figure 5-10 linuxconf IP Setup Window

5. Arrow down on the keyboard to the IP Address and type in the IP Address to be assigned to this unit.
6. Press TAB to Accept and then Enter on the keyboard. The following screen will open.




Figure 5-11 linuxconf Routing and Gateways Window

7. Arrow down to Routing and gateways.
8. Press Enter. The following screen will open.



Figure 5-12 linuxconf 2nd page Routing and Gateways

9. Press Enter on the keyboard.



Figure 5-13 linuxconf Default Gateway Setup

10. Type in the Default Gateway.
11. Press Tab to Accept.




Figure 5-14 linuxconf Final Config Screen

12. Press Tab twice to highlight Do It. Press enter.
13. The Command window should now be displayed.
14. This completes the Network setup for the ASi 10.

After a network connection is established, type the IP address or machine name in the Address field of a web browser. The VNC Authentication screen will then be displayed, Figure 5-15 VNC Authentication Screen.




Figure 5-15 VNC Authentication Screen

Type *password* for the password and select OK. The ASi 10 Main Menu is displayed in the web-browser as shown in Figure 5-15 VNC Authentication Screen. The ASi 10 can now be controlled from the remote location, just as if you were at the console, without limitation.

Note: Any number of connections to the same ASi 10 is permitted (i.e. there is no lock-out for multiple users).

5.7 Telco Dialup

The same remote Ethernet VNC capabilities are available via modem connection. Perform the following procedures to access the ASi 10 via dialup connection.

1. On standard PC with Windows 95, 98, 2000, NT, or XP OS, set up a Dial-up Networking (DUN) account using the Windows OS Dial-up Networking Wizard.
2. Connect the ASi 10 Telco modem input jack to an analog phone line.
3. Connect the Windows PC modem to another analog phone line.
4. From the Windows PC, use the newly created DUN account to dial into the ASi 10.
5. Once the connection is established, use a web browser as described in Paragraph 5.6, and type `http://10.0.0.1` in the address field. The VNC Authentication screen should now displayed (*Figure 5-15 VNC Authentication Screen*).

Note: Once the DUN connection is made, any TCP/IP-based client application can be run on the Windows PC to interact with the ASi 10 (e.g. telnet, ftp, Exceed, ssh, etc.).

Note: The DUN connection assigns IP addresses to both the ASi 10 and Windows PC. The IP address assigned to the ASi is 10.0.0.1 and the IP address assigned to the Windows host is 10.0.0.2

6 Software Upgrade

6.1 Software Upgrade Overview

CAUTION: This process removes all user software/data from the hard drive.

Obtain the proper version and place the CD into the rear CDROM and reboot the ASi 10. The iBiquity Digital Reference Platform Install screen is displayed.

The upgrade advances without interdiction.


After approximately 9 minutes, the CD should eject and the ASi will reboot.

NOTE: All network configuration (name, ip number...) is saved and need not be reset.

6.1.1 Software Upgrade Detail


The update software for the ASi 10 is contained on a single CD-ROM that is placed in the ASi 10 CD-ROM drive. The internal hard drive will be overwritten.

1. Make sure transmitter is off.
2. Disconnect AM Phase Out coax from back of ASi 10 to Tx.
3. Turn on ASi -10 if not already on. Allow Exciter to fully boot as shown below.

Disconnect Options Clipboard Send Ctrl-Alt-Del			
 © 2002 Ibiquty Digital Corporation		Version 1.5.2 more>>	Mon Jul 28 14:50:16 2003
:1102: [Warning: GPS is not time locked. Mode is WARM UP]		OPERATIONAL NO ALARM	
Band <input type="text" value="AM"/>	<input type="button" value="Operational"/> <input type="button" value="Test"/>		
Frequency <input type="text" value="930"/>	<input type="button" value="Shutdown"/>	<input type="button" value="Primary Sideband Power Level"/>	
Digital Carrier Control <input checked="" type="radio"/> On <input type="radio"/> Off	<input type="button" value="Analog Audio Diversity"/>	<input type="button" value="Analog Gain"/>	
Audio Bypass <input type="text" value="None"/>	<input type="button" value="GPS Data"/>	<input type="button" value="Magnitude Channel DC offset"/>	
Station Callsign <input type="text" value="WXYZ"/>	<input type="button" value="System Status Log"/>	<input type="button" value="Magnitude/Phase Delay"/>	
Enhanced Carrier Power Level <input type="text" value="Normal"/>	<input type="button" value="System Configuration"/>	<input type="button" value="I/Q Scale Factor"/>	
Analog Modulation <input type="text" value="On"/>	<input type="button" value="Station Interface"/>	<input type="button" value="Log Levels"/>	
Analog Audio Bandwidth <input type="text" value="5kHz"/>	<input type="button" value="Audio Levels"/>	<input type="button" value="Log Parameters"/>	
Sideband Indicator <input type="text" value="Lower"/>	<input type="button" value="Screen Resize"/>	<input type="button" value="Station Information Schedule"/>	
AM Layer 1 Service Mode <input type="text" value="MA1"/>	<input type="button" value="Versions"/>	<input type="button" value="Station Information"/>	
	<input type="button" value="Configure Password"/>		


4. The software has default values of delay that should be close to the required delay to synchronize the analog and digital audio. You will need to readjust the Analog audio diversity delay on your actual system due to delays such as processing delay. Write the current delay down in case of needing to revert to the previous version

Audio Diversity Delay _____



5. Record Analog Gain – Default (1.0)

Analog Gain _____



6. Please record Magnitude Channel DC Offset -Default (-1.0)

Magnitude Channel DC Offset _____

Magnitude DC Channel (-2.0000 - 2.0000) -1.0000

		7	8	9
		4	5	6
Back Space	Erase Field	1	2	3
Prev Field	Next Field	0	+/-	.
<-	->			Exp
		Apply	Close	Enter


7. Record Magnitude/Phase Delay. Default value is 10859.

Magnitude/Phase Delay _____

Magnitude/Phase Delay Status

Selected	Magnitude/Phase Delay	Value	Increment
<input checked="" type="radio"/>	Day	10859	1
<input type="radio"/>	Night	10859	1
<input type="radio"/>	Description	1	1
<input type="radio"/>	Description	1	1
<input type="radio"/>	Description	1	1
<input type="radio"/>	Description	1	1
<input type="radio"/>	Description	1	1
<input type="radio"/>	Description	1	1

8. Please record any other parameters or settings that you may have adjusted from the default settings such as Station Call Sign, and Analog Audio Bandwidth on the main screen. Defaults are WXYZ and 5 KHz respectively. _____
9. Open CD ROM drive on back of unit (push button on CD tray) and place BE software CD in tray. For the ASi 10 use latest CD ROM. Ensure CD is snapped onto spindle of CD ROM drive.
10. Press "OS Restart" on "Shutdown" menu and then "OK".



11. The ASi 10 should automatically start reboot process.
12. Software will automatically load in about 15 minutes.
13. CD will automatically eject when finished.
14. Remove CD and close tray.
15. Exciter will automatically reboot and start up the exciter program. This will take approximately 5 minutes.
16. For the ASi 10 the default frequency is 930 KHz after reloading software. Press "Frequency" on the display and then enter the correct carrier frequency.

Frequency (500 - 1800)		930		kHz
		7	8	9
		4	5	6
Back Space	Erase Field	1	2	3
Prev Field	Next Field	0	+/-	.
<-	->			Exp
		Apply	Close	Enter

17. Unit should be running with no errors (errors show in red) on the System Status Log screen. If errors show up, please try to reinstall again starting at step 9. If errors persist, please call BE customer service.

System Status

08:44:59:223:admxx.sync.c:0298: [gps is not time locked, getting local time to s
08:45:19:812:tsmx.x:tsmcm.c:1102: [Warning: GPS is not time locked. Mode is v

Error count 0
Warning count 2

Last Log

08:45:19:812:tsmx.x:tsmcm.c:1102: [Warning: GPS is not time locked. Mode is WA

Clear Log
X Close

18. Re-input values previously recorded.
19. If alarm display is flashing red, this is generally due to GPS not being locked. It is not necessary for GPS to be locked for the system to operate. To eliminate the flashing alarm display press "Station Interface" on the exciter front panel touch screen and then "Clear Alarm".

© 2002 Ibiquty Digital Corporation Version 1.5.2 [more>>](#) Mon Jul 28 14:50:16 2003

1102: [Warning: GPS is not time locked. Mode is WARM UP] OPERATIONAL NO ALARM

Band: AM

Frequency: 930

Digital Carrier Control: ☒ On ☐ Off

Audio Bypass: None

Station Callsign: WXYZ

Enhanced Carrier Power Level: Normal

Analog Modulation: On

Analog Audio Bandwidth: 5kHz

Sideband Indicator: Lower

AM Layer 1 Service Mode: MA1

Operational Test

Shutdown

Analog Audio Diversity

GPS Data

System Status Log

System Configuration

Station Interface

Audio Levels

Screen Resize

Versions

Configure Password

Primary Sideband Power Level

Analog Gain

Magnitude Channel DC offset

Magnitude/Phase Delay

I/Q Scale Factor

Log Levels

Log Parameters

Station Information Schedule

Station Information

Station Interface

State	Inputs	State	Outputs
1 High	1: Digital Carrier On	1 On	1: Digital Carrier On/Off Status
1 High	2: Digital Carrier Off	1 Done	2: Audio Ramp Up/Down Status
1 High	3: Audio Ramp Up To Delay	1 Done	3: Audio Delay In/Decrease Status
1 High	4: Audio Ramp Up From Delay	0 Normal	4: Audio-A Bypass Status
1 High	5: Audio Delay Increase	0 Normal	5: Audio-B Bypass Status
1 High	6: Audio Delay Decrease	1 Day	6: Day/Night Status
1 High	7: Audio-A Bypass On	0 ---	7: System Shutdown Status
1 High	8: Audio-A Bypass Off	1 OK	8: System Operational Status
1 High	9: Audio-B Bypass On	1 Alarm	9: System Alarm Status
1 High	10: Audio-B Bypass Off	0	10:
1 High	11: Day	0	11:
1 High	12: Night	0	12:
1 High	13:	0 Normal	13: Audio-A Bypass Status (R)
1 High	14: System Shutdown	0 Normal	14: Audio-B Bypass Status (R)
1 High	15: System Power On/Off Toggle	1	15:
1 High	16: System Reset	0 OK	16: System Operational Status

Test State: Stopped

☐ Enable Watchdog

Clear Alarm Start Test Stop Test X Close

20. Reconnect AM Phase Out from ASi 10 to Tx.

21. Transmitter is ready to be turned on.



7 BE Part Numbers

This section provides parts lists for the ASi-10 IBOC Digital Signal Generator. The parts lists provide descriptions and part numbers of electrical components, assemblies, and selected mechanical parts required for maintenance. Each parts list entry in this section is indexed by reference designators appearing on the applicable schematic diagrams.

This bill of material uses an indented structure to show relationships of parts into sub assemblies. Example; all BOM LEVEL 2 parts are contained in the BOM LEVEL 1 part immediately above it.

BOM LEVEL	PART NO.	DESCRIPTION	QTY	REF. DES.
0	909-6026-MB3	ASi-10,HD,DIGITAL SIGNAL GENERATOR,MB3		
..1	229-8085-003	IC,CPU,P4,3.0GHz FSB,FSi/ASi/XPi	1	
..1	380-0310	FAN,12v,150 CFM	1	
..1	380-4831	FAN,CPU COOLER & HEATSINK,INTEL P4	1	
..1	400-1725	STRIP,QUIET SHIELD,17.25x.394	1.08	
..1	401-0015	MTG,ADH BACK,SMS-A-15-PANDUIT	1	
..1	402-0000	TY-RAP	18	
..1	402-0005	PRESS CLIP,NYLON W/ADHESIVE BACK	4	
..1	402-0006	MT,ADH BACKED,FOR CBL TIES	7	
..1	402-0008	MTG DEVICE,FOR #6SCR,TIE CBL	1	
..1	402-0047	TY-WRAP, 14.6 LOOP, 40LBS, BLACK	1	
..1	402-0051	TY-RAP, W/FLAG	12	
..1	403-0008	BUMPER, RUBBER, RECESS STYLE, 11/32 TALL"	3	
..1	407-0176	FILTER, AIR, ELECTROMAZE ESF 5.500 X 8.500 X .25	1	
..1	409-5500	CARD GUIDE,BIVAR VERT-O-GUIDE VG3-6	1	
..1	410-0101-001	DISPLAY, COLOR LCD, FLAT PANEL, TOUCH SCREEN,XPi/ASi/FSi DSG	1	
..1	417-0017	RECP,BNC,BULKHEAD,UG-492A/U	1	
..1	420-0817	ASSY,FEMALE SCREWLOCK 205817-1	3	
..1	420-2104	SCREW,2-56X.250,S.S. PH SC	8	
..1	420-2704	SCREW,M2 X 4,PHILLIPS PAN HEAD,SS	4	
..1	420-3710	SCREW,M3 X 10,PHILLIPS PAN HEAD,SS	18	
..1	420-4103	SCREW,4-40X.187,S.S. PH	6	
..1	420-4105	SCREW,4-40X.312,S.S. PH	4	
..1	420-6002	SCREW,6-32X.437,S.S. PH FH UC	1	
..1	420-6112	SCREW,6-32X.750,S.S. PH	1	
..1	420-6514	SCREW,6-32X.875,S.S. PH FH	4	
..1	420-6605	SCREW,6-32X.312,S.S. PH FH UC	13	
..1	421-0102	10-32 KEP NUT	1	
..1	421-4008	4-40 KEP NUT	6	
..1	421-6005	6-32 ELASTIC STOP HEX NUT	5	
..1	421-6011	6-32 S.S. HEX THICK NUT	1	
..1	421-8028	NUT,JAM,1/2-28 UNEF-2B	5	
..1	422-6106	SCREW,SEMS 6-32 X 3/8 PAN PH. ST."	75	
..1	422-6107	SCREW,SEMS 6-32 X 7/16 PAN PH.ST."	12	
..1	423-2002	#2 LOCK SPLIT	20	
..1	423-4002	#4 LOCK S.S. SPLIT	24	



BOM LEVEL	PART NO.	DESCRIPTION	QTY	REF. DES.
..1	423-6006	#6 FLAT, 0.75 O.D, 0.140 I.D., 0.062 THK, SST	3	
..1	423-6011	#6 FLAT .310 X .160 X .030	4	
..1	423-9002	WASH,INT TOOTH,1/2	5	
..1	441-0000	STOFF, #2-56 X .25 L, 5/32 HEX, MF, SST"	4	
..1	441-5402	STOFF,#4-40 ALUM 3/16HEX X 3/4"LONG"	6	
..1	453-0027	BRKT, SERIAL CARD, FSI-10	1	
..1	471-5333	ANGLE,FRONT PANEL MOUNT,DTC EXCITER	2	
..1	471-5336-100	PANEL,FRONT,NEW PCB,DIGITAL SIGNAL GENERATOR	1	
..1	471-5337-200	CHASSIS,NEW,DIGITAL SIGNAL GENERATOR	1	
..1	471-5338	PANEL,REAR,DIGITAL SIGNAL GENERATOR	1	
..1	471-5339-200	COVER,NEW,TOP,DIGITAL SIGNAL GENERATOR	1	
..1	471-5340	ANGLE,PCB MOUNT,DIGITAL SIGNAL GENERATOR	4	
..1	471-5341-200	BRACE,NEW,PCB SUPPORT,DIGITAL SIGNAL GENERATOR	1	
..1	471-5343	BRACKET, CD-ROM, DIGITAL SIGNAL GENERATOR	1	
..1	471-5453	ANGLE,DAUGHTER CARD BRACE SUPPORT,FSi10/ASi10/XPi10	1	
..1	500-210	Screw,SEMS 4-40x1/4 Phil Pan Head MS Blk Zinc(external lock)	22	
..1	586-149	9 inch Phone Jumper (SBCM)	1	
....2	550-279	Connector,Line Plug 6 Pos 4 Conn Adamtech #ADTMTP6-4-U	2	
....2	580-154	Cable,26 AWG/4C Silver Satin #M264SS	0.75	
..1	591-0036	LABEL,POWER,DTC EXCITER	1	
..1	591-0038	LABEL,GPS LOCK,DIGITAL SIGNAL GENERATOR	1	
..1	591-0039	NAMEPLATE,ASi10,AM DIGITAL SIGNAL GENERATOR	1	
..1	594-0073	LABEL,WARNING ROTATING FANS	2	
..1	594-0503	LABEL, DANGER-HAZARDOUS VOLTAGE	1	
..1	594-0505	LABEL, WARNING-ONLY AUTHORIZED PERSONNEL	1	
..1	611-1501	TUB,HT SHK,1-1/2ID,BLACK"	1	
..1	700-0148	TAPE,JOINING 3/4	0.001	
..1	849-0680	CBL, ASSY, COAX 18, OSX RT-OSX STRAIT"	5	
..1	849-0681	CBL, ASSY, COAX 18, OSX RT-BNC"	1	
..1	849-0682	CABLE, USB, 20 INCH	2	
..1	849-0683	CABLE, VGA, HDDB15M TO HDDB15M, 2 FOOT	1	
..1	849-6027	POWER SUPPLY CABLE MOLEX 4 PIN MALE TO FLOPPY DRIVE FEMALE	1	
..1	919-0548-002	PCB, ASSY, DIGITAL UPCONVERTER II (SBCM)	1	
....2	007-0018-006	CAP,0603,18pF,50V,5%	3	C10, C73, C132



BOM LEVEL	PART NO.	DESCRIPTION	QTY	REF. DES.
....2	007-0047	CAP,4.7uF,16v,20%,SMD,3216/Y	3	C9, C253, C254
....2	007-0056-006	CAP,56pF,50v,5%,0603	1	C75
....2	007-0082-006	CAP,82pF,50V,5%,0603	2	C74, C93
....2	007-0153	CAP,CER, .015uF,25V,10%,0603,SMD	1	C89
....2	007-0207-006	CAP,0.27uF,6.3v,10%,0603	1	C8
....2	007-0220-006	CAP,220pF,50v,5%,0603	1	C79
....2	007-0222	CAP,CER, 2.2uF, 16V, 10%, 1206, SMD	6	C136, C140, C156, C160, C174, C178
....2	007-0270-006	CAP,270pF,50v,5%,0603	1	C76
....2	007-0390-006	CAP,390pF,50v,5%,0603	1	C78
....2	007-0470-006	CAP,470pF,50v,10%,0603	1	C77
....2	007-1034-001	CAP,CER,.01UF,10%,50V,0603,SMD	40	C7, C125, C138, C142, C151, C152, C153, C154, C155, C158, C162, C169, C170, C171, C172, C173, C176, C180, C189, C190, C191, C192, C193, C199, C200, C201, C202, C203, C222, C223, C224, C225, C226, C240, C241, C242, C243, C244, C246, C248
....2	007-1040-025	CAP,CER,.1UF,+80,-20%,25V,0603,SMD	109	C1, C5, C12, C13, C14, C17, C60, C61, C62, C64, C66, C67, C68, C69, C70, C71, C80, C81, C84, C85, C86, C87, C88, C90, C91, C94, C96, C98, C99, C103, C105, C107, C109, C110, C111, C116, C118, C121, C122, C124, C127, C128, C129, C130, C131, C135, C137, C141, C146, C147, C148, C149, C150, C157, C161, C164, C165,
....2	007-1054	CAP,CER,1uF,50V,10%,SMD	1	C126
....2	007-1054-002	CAP,CER,1000PF,+80,-20%,50V,0603,SMD	9	C2, C4, C139, C143, C159, C163, C177, C181, C252
....2	007-1500	CAP,CER,1500pF,50V,10%,0603,SMD	1	C92
....2	007-1800-006	CAP,1800pF,50V,10%,SMD,0603	1	C113
....2	007-2724-500	CAP,CER,.0027uF,50V,10%,SMD	1	C101
....2	007-8213-500	CAP,CER,820pF,50V,5%,SMD	4	C100, C102, C108, C117

BOM LEVEL	PART NO.	DESCRIPTION	QTY	REF. DES.
....2	070-0335	CAP,TANT,3.3uF,20V,10%,B,SMD	17	C22, C25, C27, C29, C32, C36, C37, C38, C39, C47, C48, C49, C50, C52, C54, C255, C257
....2	070-1064	CAP,TANT,10uF,35V,20%,SMD	4	C3, C6, C16, C53
....2	070-1084	CAP,TANT,100uF,16V,10%,SMD	11	C21, C28, C33, C34, C45, C46, C133, C134, C182, C183, C256
....2	070-1564	CAP,TANT,15uF,35V,10%,SMD	3	C59, C83, C95
....2	070-6854	TANT CAP, 6.8 UF, 16V, SIZE C	14	C11, C15, C63, C65, C72, C82, C97, C104, C106, C112, C115, C119, C120, C123
....2	070-6864	CAP,TANT,68uF,25V,20%,SMD	6	C23, C24, C26, C30, C31, C51
....2	101-0003	RES,THICK FILM,0 OHM,1/8W,5%,SMD	1	R11
....2	102-2000	RES,CHIP,200 OHM,1/10 W,1% SMD	3	R81, R82, R93
....2	102-2353	RES,CHIP,23.7K OHMS,1/10W,1%,SMD	1	R77
....2	102-3001	RES,CHIP,30.1 OHMS,1/10W,1%,SMD	1	R80
....2	102-3090	RES,CHIP,309 OHMS,1/10W,1%,SMD	1	R92
....2	102-4705	RES,CHIP, 47.5 OHM, 1%, 1W, 2512, SMD	1	R74
....2	102-6191	RES, CHIP, 6.19K OHM, 1/10W, 1%	3	R12, R13, R76
....2	102-6409	RES,CHIP,64.9 OHMS,1/10W,1%,SMD	1	R91
....2	104-0000	RES,CHIP,0 OHM JUMPER,0603,SMD	7	R4, R84, R85, R86, R87, R94, R95
....2	104-0027	RESISTOR,27.4ohm,1%,1/16W,SMD,0603	4	R33, R34, R65, R66
....2	104-0034	RES,CHIP,34 OHM,1%,1/16W,0603,SMD	1	R18
....2	104-0047	RESISTOR,47.5ohm1%,1/16W,SMD,0603	4	R42, R43, R83, R73
....2	104-0051	RESISTOR,51.1ohm1%,1/16W,SMD,0603	12	R2, R14, R36, R39, R40, R41, R49, R57, R62, R68, R72, R99
....2	104-0100	RES,CHIP,100 OHM,1%,0.10W,0603,SMD	2	R70, R96
....2	104-0120	RES,CHIP,121 OHM,1%,1/16W,0603,SMD	1	R38
....2	104-0180	RESISTOR,182ohm,1/16W,1%,SMD,0603	2	R47, R51
....2	104-0183	RESISTOR,18.2Kohm,1%,1/16W,SMD,0603	1	R55
....2	104-0220	RESISTOR,221ohm,1/16W,SMD,0603	2	R63, R61
....2	104-0510	RESISTOR,511ohm,1%,1/16W,SMD,0603	3	R75, R100, R101
....2	104-0576	RES,CHIP, 576 OHM, 1%, 1/16W, 0603, SMD	1	R90
....2	104-0750	RES,CHIP,750 OHM,1%,1/16W,0603,SMD	1	R97
....2	104-0820	RESISTOR,825ohm,1%,1/16W,SMD,0603	2	R10, R29
....2	104-1001	RES,CHIP,1.0 K OHM,1%,1/16W,0603,SMD	3	R44, R54, R58
....2	104-1002	RES,CHIP,10.0 K OHM,1%,1/16W,0603,SMD	1	R79
....2	104-1201	resistor,1.21Kohm1/16W,1%,SMD,0603	5	R3, R6, R7, R8, R24
....2	104-1802	RESISTOR,1.82Kohm1/16W,1%,SMD,0603	7	R17, R19, R22, R23, R25, R26, R28
....2	104-2000	RESISTOR,2Kohm,1/16W,1%,SMD,0603	3	R9, R52, R56
....2	104-2701	RESISTOR,2.74Kohm,1%,1/16W,SMD,0603	2	R32, R64
....2	104-3301	RES,CHIP,3.32Kohm,1%,1/16W,0603,SMD	1	R27
....2	104-4321	RES,CHIP,4.32 K OHM,1%,1/16W,0603,SMD	2	R21, R20



BOM LEVEL	PART NO.	DESCRIPTION	QTY	REF. DES.
....2	104-4701	RES,CHIP,4.75KOHM,1%,1/16W,0603,SMD	1	R59
....2	104-5105	RESISTOR,5.1M,5%,1/10W,SMD,0603	1	R1
....2	104-5112	RES,CHIP, 51.1k OHM, 1%, 1/16W, 0603, SMD	1	R71
....2	104-5600	RES,CHIP,562 OHM,1%,1/16W,0603,SMD	8	R30, R35, R37, R48, R53, R60, R67, R69
....2	104-5602	RES,CHIP, 56.2 OHM, 1%, 1/16W, 0603, SMD	2	R89, R88
....2	104-6810	RES,CHIP,681 OHM,1%,1/16W,0603,SMD	1	R78
....2	104-8200	Chip Res, 8.25K 1% 1/16W 0603 SMD	1	R15
....2	104-8202	RESISTOR,82.5K,1%,1/16W,SMD,0603	1	R5
....2	198-0203-001	TRMR, 20K OHMS, SINGLE TURN, SIDE ADJUST,SMD	1	R45
....2	201-2801	DIODE,HOT CARRIER,MMBD701LT1,SMD	1	D13
....2	204-5100	DIODE,SCHOTTKY RECTIFIER, 5A, DO-201AD	1	D28
....2	216-0420	CLC420, High Speed Voltage Feedback Op Amp SMD	4	U15, U17, U28, U31
....2	216-0640	IC,FLASH MEMORY,64MB,3V,48-PIN,TSOP	1	U36
....2	216-1004	IC,HEX INVERTING DRIVER,SOIC-14	1	U4
....2	216-1021	IC,DSP,STRATIX,25KB,1020-PIN,FPGA	1	U33
....2	216-1206	IC,CURRENT FEEDBACK AMP,250MA,60MHz	2	U3, U32
....2	216-1355	LT1355 12MHz op amp	2	U19, U20
....2	216-1386	IC,TRANSCEIVER,3.3V,200uA,SOIC-16	1	U34
....2	216-1619	IC,REMOTE/LOCAL TEMP.SENSOR,QSOP16	1	U39
....2	216-1711	IC,RAIL TO RAIL COMPARATOR,MSOP8	1	U29
....2	216-1819	IC,MICROMONITOR,3V,10%,SOT-23-5	1	U37
....2	216-2524	IC, CGS74LCT2524M 3v Clock Driver SMD	1	U42
....2	216-3256	IC,EEPROM,EPM3256A,3.3V,7.5ns,TQFP144	1	U35
....2	216-3443	IC,RS-485/J1708 TRANSCEIVER,SOIC8	1	U30
....2	216-3861	IC,CMOS,10-BIT,BUS SWITCH,QSOP24	6	U21, U22, U23, U24, U25, U26
....2	216-3904	TSTR,MMBT3904LT1,NPN,SMD	2	Q1, Q2
....2	216-4590	IC, DUAL SPST N.O.,ANALOG SWITCHES 16-PIN SSOP SMD	1	U16
....2	216-5170	IC, MC145170DT2 PLL FREQUENCY SYNTHESIZER TSSOP-16 SMD	1	U2
....2	216-6531	IC, SN65LVDS31D HIGH SPEED DIFFERENTIAL LINE DRIVER SMD	1	U41
....2	216-9754	IC,AD9754ARU D/A Converter 14BIT 125MSPS SMD	3	U14, U18, U27
....2	226-0102	RES.NET, 1K,2%, ISOLATED, 16-PIN,SMD	1	RN3
....2	226-0103	RES.NET, 0K,2%, ISOLATED, 16-PIN,SMD	5	RN1, RN2, RN4, RN6, RN7
....2	226-0560	RES.NET, 56,2%, ISOLATED, 16-PIN,SMD	1	RN5
....2	227-2931	VR, LM2931,5v SMD	5	U6, U7, U10, U11, U40
....2	227-2937	VR, LM2937,8v SMD	1	U5
....2	227-2950	VR,LOW DROPOUT,5A,ADJ.VOLTS,TO-263-5	1	U38
....2	227-7955	Negative VR MC79M05BDT,-5v SMD	1	U12

BOM LEVEL	PART NO.	DESCRIPTION	QTY	REF. DES.
....2	325-0251	LED, GRN, SMD, 0805	11	D2, D3, D4, D5, D6, D7, D8, D9, D10, D11, D12
....2	325-0252	LED,RED/ORN,1206,SMD	11	D15, D16, D17, D19, D20, D21, D22, D24, D25, D26, D27
....2	325-0254	LED, GREEN, 1206, SMD	1	D18
....2	325-0255	LED, BLUE, 0603, SMD	1	D23
....2	340-0004	SW, JUMPER PROGRAMMABLE	8	P1, P18, P19, P20, P21, P22, P25, P27
....2	342-0801	SW, DIP, 8-POS, SPST-N0, SMD	1	S2
....2	342-1001	SW, DIP, 10-POS, SPST-N0, SMD	1	S1
....2	342-3304	SW, TACT, SPST, N.O., SMD, RECESSED	2	PB1, PB2
....2	366-0180-001	INDUCTOR, 180nH, 10%, SMD, 1008	2	L1, L2
....2	366-0821	INDUCTOR, 820nH, 10%, SMD, CH1010	2	L12, L13
....2	366-0910	INDUCTOR, 910nH, 10%, SMD, 0805	1	L11
....2	366-1000	INDUCTOR, 100uH, 20%, SMD	5	L5, L6, L7, L8, L9
....2	366-3100	FERRITE, 600 OHMS, 1.5 AMP, 100MHz, 1206 SMD	11	L17, L19, L22, L24, L26, L27, L28, L29, L30, L31, L32
....2	366-4100	FERRITE, 60 OHMS, 6 AMP, 100MHz, 1806 SMD	1	L20
....2	366-4700	INDUCTOR, FIXED, 4.7uH, 1210, SMD	2	L14, L15
....2	390-5953	VCUGLA at 59.535MHz VCXO SMD	1	U1
....2	408-0300	HEADER, 3-PIN, .100 CENTERS, SIP, note	2	J25, J27
....2	408-0801	HEADER, 8-PIN, .100 CENTERS, DIP, SMD	1	J5
....2	408-3800	CONN, HEADER, 38-PIN, DIP, .025 CTR, SMD	2	J11, J12
....2	413-0106	TERM, TEST POINT, OVAL, RED	21	TP1, TP2, TP3, TP4, TP5, TP6, TP7, TP8, TP9, TP10, TP11, TP12, TP13, TP14, TP15, TP16, TP17, TP18, TP19, TP20, TP21
....2	417-0070	CONN, HEADER 4 PIN	1	J7
....2	417-0199	CONN, 9PIN D, FEMALE, RTANG, PCBM	1	J28
....2	417-1020	CONN, HEADER 2-PIN VERTICAL SIP SMD	6	J1, J18, J19, J20, J21, J22
....2	417-1023	CONN HEADER, 10-PIN RT ANGLE, PCB MAL	2	JP1, J13
....2	417-2284	CONN MCX RIGHT ANGLE JACK 50 OHM PCB MOUNT	6	J2, J4, J8, J38, J39, J40
....2	417-4040	CONNECTOR, HEADER STRAIGHT POST	2	J15, J17
....2	417-5565	CONN 8-PIN MODULAR JACK RT ANGLE PCB MOUNT SHIELDED	2	J41, J43
....2	417-9013	CONN, HEADER, SHROUDED, 12-PIN, RT. ANGLE	1	J16
....2	418-1108	SOCKET, OSCILLATOR, 4-PIN, 8-POS, DIP	1	J26
....2	453-0000	BRACKET, PC PCB, KEYSTONE 9203	1	H1
....2	479-0175	SHIELD, 1.5x1.75"x1.0", PC MOUNT	3	
....2	519-0548-002	PCB, MACH, DIGITAL UP CONVERTOR II	1	
..1	919-0549	PCB, ASSY, STATION INTERFACE, FM-IBOC & AM-IBOC, DSG(SBCM)	1	



BOM LEVEL	PART NO.	DESCRIPTION	QTY	REF. DES.
....2	007-0020-006	CAP,20pF,5%,50v,SMD,0603	2	C26, C27
....2	007-1044-025	CAP,CER,100 NFD,10%,25V,1206,SMD	13	C7, C8, C11, C13, C17, C18, C22, C23, C25, C30, C31, C33, C34
....2	007-4744-050	CAP, CER, .47UF, 50V, -20% TO +80%	3	C28, C29, C32
....2	070-0010	Cap,Lytic 10uF 16V SMD	2	C2, C35
....2	104-0039	RESISTOR,39ohm,5%,.1W,SMD,0603	1	R6
....2	104-0330	resistor,332ohm,1/8W,1%,SMD,1206	4	R20, R21, R22, R23
....2	104-1802	RESISTOR,1.82Kohm1/16W,1%,SMD,0603	4	R24, R25, R27, R28
....2	104-4701	RES,CHIP,4.75KOHM,1%,1/16W,0603,SMD	1	R18
....2	104-4701-001	RES,CHIP,4.75KOHM,1%,1/8W,1206,SMD	1	R32
....2	229-0705	IC, MAX705CSA Microprocessor Supervisor SMD	1	U5
....2	229-3221	IC,RS 232 TRANSCEIVER +3V TO +5V 1uA SUPPLY-CURRENT	1	U24
....2	320-1371	LED,LNJ306G5TRW GREEN SMD	2	D1, D2
....2	340-0004	SW,JUMPER PROGRAMMABLE	5	P3, P89, P90, P94, P95
....2	390-2000	XTAL,20MHz, CYL XTAL CA-301 Type	1	Y1
....2	417-0003	CONN,HEADER 3 PIN	1	J3
....2	417-0173	CONN,PCB,40-PIN,609-4037	1	J135
....2	417-1050	.100,10 pin double row terminal strip"	3	J113, J115, J116
....2	417-2524	SHROUDED HEADER 24 POS STRAIGHT	1	JP1
....2	417-4004	CONN,HEADER,2 PIN	5	J89, J90, J94, J95, J130
....2	417-5163	Mod Jack 6-6 low profile w/stops	1	J8
....2	418-1001-001	CONN, MALE, 10 PIN, LONG LATCH, PCB MT	1	J133
....2	418-1003	CONN,PCB 10PIN(DUAL 5)	1	J2
....2	453-0000	BRACKET,PC PCB,KEYSTONE 9203	1	
....2	500-210	Screw,SEMS 4-40x1/4 Phil Pan Head MS Blk Zinc(external lock)	2	
....2	519-0549	PCB, MACH, STATION INTERFACE, FM-IBOC & AM-IBOC, DSG	1	
....2	979-0549-U11	KIT,SOFTWARE,CPLD,U11,SIC	1	U11
.....3	229-4192	HIGH PERFORMANCE E*CMOS	1	U11
....2	979-0549-U4	KIT,SOFTWARE,EEPROM,U4,SIC	1	U4
.....3	229-0877	IC,EEPROM MCU LDS 20MHz 8K Flash TQFP SMD	1	U4
..1	919-0550	PCB,ASSY,SAMPLE RATE CONVERTER,ASi/XPi (SBCM)	1	
....2	007-0183	CAP CERAMIC,0.018uF,25V,10%,SMD 0805,X7R	1	C3
....2	007-0823	Cap, 0.082uF,50V ceramic SMD	1	C4
....2	007-1024	CAP,CER,.001uF,50V,10%,SMD	2	C9, C11
....2	007-1034	CAP,CER,0.01uF,50V,10%,SMD	3	C1, C23, C34
....2	007-1044	CAP,CER,0.1uF,50V,10%,SMD note	14	C13, C22, C27, C28, C30, C43, C45, C46, C47, C48, C49, C50, C51, C31
....2	007-2224-500	CAP,CER,.0022uF,50V,10%,SMD	1	C26

BOM LEVEL	PART NO.	DESCRIPTION	QTY	REF. DES.
....2	007-3313	CAP,CER,330pF,50V,5%,SMD	5	C5, C6, C7, C8, C10
....2	007-4724	CAP,CER,0.047uF,50V,10%,SMD	1	C52
....2	070-1054	CAP,TANT,1uF,35V,10%,SMD	6	C2, C12, C24, C29, C44, C32
....2	070-1064	CAP,TANT,10uF,35V,20%,SMD	3	C14, C15, C16
....2	101-2432	RES,CHIP,24.3K OHM,1%,1/8W,1206,SMD	1	R11
....2	102-0000	RES,CHIP,0 OHM,0805,SMD	13	R68, FL1, FL2, FL3, FL4, FL5, FL6, FL7, FL8, FL9, FL10, FL11, FL12
....2	102-0100	RES,CHIP,10.0 OHMS,1/10W,1%,SMD	1	R15
....2	102-1000	RES,CHIP,100 OHMS,1/10W,1%,SMD	2	R16, R21
....2	102-1001	RES,CHIP,1.00K OHMS,1/10W,1%,SMD	16	R5, R22, R23, R24, R27, R33, R35, R36, R37, R38, R39, R49, R50, R57, R62, R66
....2	102-1002	RES,CHIP,10.0K OHMS,1/10W,1%,SMD	5	R4, R7, R8, R13, R34
....2	102-1003	RES,CHIP,100K OHMS,1/10W,1%,SMD	1	R60
....2	102-1004	RES,CHIP,1.00M OHMS,1/10W,1%,SMD	2	R2, R3
....2	102-1133	RES,CHIP,110 OHMS,1/10W,1%,SMD	3	R25, R40, R41
....2	102-1825	RES,CHIP,18.2 K OHM,1/10W,1%	1	R17
....2	102-2212	RES,CHIP,22.1K OHMS,1/10W,1%,SMD	2	R48, R64
....2	102-2410	RES,CHIP,243 OHMS,1/10W,1%,0805,SMD	5	R20, R32, R58, R61, R69
....2	102-2940	RES,CHIP,294 OHMS,1/10W,1%,SMD	2	R70, R71
....2	102-3011	RES,CHIP,3.01K OHMS,1/10W,1%,SMD	1	R26
....2	102-3012	RES,CHIP,30.1K,1/10W,1%,SMD	1	R9
....2	102-3321	RES,CHIP,3.32K OHMS,1/10W,1%,SMD	1	R6
....2	102-4711	RES,CHIP,475 OHMS,1/10W,1%,SMD	1	R14
....2	102-4755	RES,CHIP,47.5K OHM,1/10W,1%	9	R18, R28, R29, R30, R42, R43, R45, R46, R47
....2	102-4872	RES,CHIP,48.7K,1/10W,1%,SMD	1	R10
....2	102-5112	RES,CHIP,51.1 OHM,1/10W,1%	2	R1, R44
....2	102-7150	RES,CHIP,715 OHMS,1/10W,1%,SMD	1	R19
....2	179-2043	RES,TRMR,2K,15 TURN 3006	1	R72
....2	204-0914	DIODE,SWITCHING,MMBD914LT1,SMD	3	D1, D3, D4
....2	205-0833	VARIABLE CAPACITANCE DIODE, SOT-23 SMD	1	D2
....2	210-3906-001	TSTR,3906,SMD	1	Q2
....2	216-0634	IC, BUFFER, BUF634U, SO-8, SMD	1	U13
....2	216-3904	TSTR,MMBT3904LT1,NPN,SMD	2	Q1, Q3
....2	216-4013	IC,MC14013BD DUAL D FLIP FLOP,SMD	1	U12
....2	216-4111	IC,OPAMP,RAIL TO RAIL,300mA,SOIC-8	1	U7
....2	216-7002	IC,MOSFET,2N7002LT1,SMD	2	Q4, Q5
....2	216-7414	IC,74AC14,HEX INVERTER,SCHMITT TRIG,SO-14,SMD	1	U4
....2	220-1451	IC, CMOS PLL FREQUENCY SYNTHESIZER	1	U3
....2	220-8922	IC, Dual Differential Line Driver SMT	1	U2
....2	224-0708	IC, MICRO SUPERVISOR, 3V, SMD	1	U14
....2	224-8420	IC, SAMPLE RATE CONVERER 96 KHZ	1	U1



BOM LEVEL	PART NO.	DESCRIPTION	QTY	REF. DES.
....2	228-0161	IC,74ACT161,SYNCH. BINARY COUNTER,16-PIN SMD,SOIC	2	U10, U11
....2	231-3170	VR,LM317,SMD	1	U5
....2	270-0066	REL,DPDT,12VDC,DIP	1	K1
....2	270-470	Cap,monolithic chip,47 pf 50v 5% Kemet C1206C470J5GACTR	2	C53, C54
....2	325-0250	LED,DUAL RED/GREEN,LOW PROFILE,SMD	2	DS1, DS2
....2	340-0004	SW,JUMPER PROGRAMMABLE	4	P12, P13, P14, P15
....2	350-030	INDUCTOR, 3.0 - 7 UH W/SHIELD CAN #47271-023	1	L1
....2	366-0010-001	IND,10UH,1.5A	2	L3, L4
....2	366-0011	IND,10UH,SHIELDED,SMD	1	L2
....2	367-9370	XFMR,SMT,AES/EBU,SC937-02	3	T1, T2, T3
....2	408-0300	HEADER,3-PIN,.100 CENTERS,SIP,note	4	J12, J13, J14, J15
....2	413-1206	CHIP,TEST POINT,1206,SMD	3	TP9, TP10, TP11
....2	417-0265	CONN,BNC,JACK,THREADED,PC EDGE MOUNT,LOW PROFILE	1	J11
....2	417-0804	SOCKET,8-PIN DIP,BURNDY	1	XU6
....2	417-1550-002	CONN,HEADER,RT.ANGLE,2-PIN,3.81MM SPACING,PCB MOUNT	1	J3
....2	417-2284	CONN MCX RIGHT ANGLE JACK 50 OHM PCB MOUNT	2	J1, J16
....2	417-2838	HEADER 4-PIN .100 R.ANGLE LOCKING"	1	J2
....2	417-7188	CONN,RJ-45 JACK SINGLE PORT 8-PIN SHIELDED PCB MOUNT	1	J9
....2	418-0060	RECEPTACLE,XLR,3-PIN,FEMALE,RIGHT ANGLE,PCB MOUNT	2	J4, J10
....2	418-0061	RECEPTACLE,XLR,3-PIN,MALE,RIGHT ANGLE,PCB MOUNT	3	J6, J7, J8
....2	431-1600	SOCKET,16-PIN,DIP,SMD note	1	XK1
....2	479-0175	SHIELD,1.5x1.75"x1.0",PC MOUNT"	1	
....2	519-0550	PCB, MACH, AM, SAMPLE RATE CONVERTER	1	
....2	979-0550-U6	KIT,SOFTWARE,MICRO,U6,AM/SRC	1	U6
.....3	229-0519	Microprocessor 8pin DIP PIC12CE519-04/P	1	U6
..1	919-0551	PCB, ASSY, XLR-BNC I/O INTERFACE, FM & AM-IBOC, DSG(SBCM)	1	
....2	007-0047	CAP,4.7uF,16v,20%,SMD,3216/Y	1	C10
....2	007-1044	CAP,CER,0.1uF,50V,10%,SMD note	9	C1, C2, C3, C4, C5, C6, C7, C8, C9
....2	104-0020	RES,20ohm,.25W,1%, SMD, 1210	1	R11
....2	104-0036	RES,35.7ohm,.25W, 1%, SMD, 1210	3	R9, R16, R17
....2	104-0051-063	RES,51.1ohm,.25W,1%,SMD,1210	1	R6
....2	104-0103	RES,10Kohm,.1W,1%, SMD, 0603	1	R12
....2	104-0122	res,1.2Kohm,.1W,5%, SMD, 0603	1	R2
....2	104-0165	RES,16.5ohm,.25W, 1%, SMD, 1210	1	R18
....2	104-0200	RES,200ohm,.1W,5%, SMD, 0603	1	R1
....2	104-0242	RES,2.4Kohm,.1W,5%,SMD,0603	1	R13
....2	104-0303	RES,30.1Kohm,.1W,1%,SMD,0603	4	R4, R5, R7, R8
....2	104-0390	RES,390ohm,.25W,5%,SMD,1206	1	R14
....2	104-0620	RES,620ohm,.1W,5%,SMD,0603	1	R3

BOM LEVEL	PART NO.	DESCRIPTION	QTY	REF. DES.
....2	216-0111	IC,Closed loop buffer, Ultra high slew rate, 8 pin SMD	3	U1, U2, U3
....2	227-1128	IC,VR,8V,LOW DROPOUT,SOT23-5L,SMD	1	U4
....2	320-0603	LED GREEN SMD	1	D1
....2	340-0004	SW,JUMPER PROGRAMMABLE	16	P5A, P5B, P6A, P6B, P7A, P7B, P8A, P8B, P9A, P9B, P10A, P10B, P11A, P11B, P12A, P12B
....2	367-1128	XFMR, 5MHz-120MHz SMD	1	T1
....2	411-0103	Chip,EMI Filter,10,000pF 50V 20% SMD	1	L1
....2	411-0222	Chip EMI Filter, 2200pF 50V 20% SMD	8	L2, L3, L4, L5, L6, L7, L8, L9
....2	417-0037	BNC,R ANGLE PC MT 227161-1 AMP (NOTE)	5	J1, J2, J3, J4, J5
....2	417-1701	STRAIGHT JACK RECEPTACLE,SMB PCB MOUNT 50 OHM	1	J11
....2	417-2284	CONN MCX RIGHT ANGLE JACK 50 OHM PCB MOUNT	6	J6, J7, J8, J9, J10, J12
....2	417-2600	CONN,HEADER,26PIN	2	JP5, JP6, JP7, JP8, JP9, JP10, JP11, JP12
....2	417-2838	HEADER 4-PIN .100 R.ANGLE LOCKING"	1	JP3
....2	417-4209	CONN,DUAL-PORT D-SUB,9-PIN,MALE,PCB MOUNT	1	P1
....2	418-0058	RECEPTACLE XLR FEMALE RT. ANGLE PCB MOUNT	4	JR1, JR2, JR7, JR8
....2	418-0059	RECEPTACLE XLR MALE RT. ANGLE PCB MOUNT	4	JR3, JR4, JR5, JR6
....2	418-1003	CONN,PCB 10PIN(DUAL 5)	2	JP1, JP2
....2	519-0551	PCB, MACH, XLR-BNC I/O INTERFACE, FM-IBOC & AM-IBOC, DSG	1	
..1	919-0552	PCB, ASSY, RJ-45/USB/DB-9 I/O INTERFACE, FM&AM-IBOC,DSG	1	
....2	417-0318	CONN,USB TYPE A DOUBLE PCB MOUNT	1	JP13
....2	417-0319	Conn,USB Type B Single Right Angle PCB Mount	2	JP14, JP15
....2	417-6466	CONN,RJ-11 JACK SINGLE PORT 6-PIN SHIELD PCB MOUNT	2	JP11, JP12
....2	417-7187	CONN,RJ-45 JACK 4-PORT 8-PIN SHIELDED PCB MOUNT	1	P1
....2	417-7188	CONN,RJ-45 JACK SINGLE PORT 8-PIN SHIELDED PCB MOUNT	6	P2, P3, P4, P5, P6, P7
....2	418-1003	CONN,PCB 10PIN(DUAL 5)	1	JP1
....2	519-0552	PCB,MACH,RJ-45/USB/DB-9 I/O INTERFACE,FM-IBOC & AM-IBOC,DSG	1	
..1	919-0553	PCB,ASSY,TERMINAL STRIP I/O INTERFACE,FM & AM-IBOC,DSG(SBCM)	1	
....2	007-1044	CAP,CER,0.1uF,50V,10%,SMD note	3	C13, C14, C15
....2	063-1074	CAP,TANT,10UF,25V,20%	6	C7, C8, C9, C10, C11, C12
....2	101-0390	RES, 390ohm, 1W, 5%, SMD, 2512	2	R10, R11



BOM LEVEL	PART NO.	DESCRIPTION	QTY	REF. DES.
....2	104-3301	RES,CHIP,3.32Kohm,1%,1/16W,0603,SMD	2	R12, R13
....2	204-0052	Silicon Rectifier 2A 50V SMD	12	D1, D2, D3, D4, D5, D6, D7, D8, D9, D10, D11, D12
....2	204-0718	Diode Network Schottky Barrier Diodes	5	DN1, DN2, DN3, DN4, DN5
....2	216-0621	Multi-Channel Phototransistor Optocoupler	4	U1, U2, U3, U4
....2	216-7414	IC,74AC14,HEX INVERTER,SCHMITT TRIG,SO-14,SMD	3	U13, U14, U15
....2	226-3301	res net, 3.3Kohm, smd, 2512	2	R4, R5
....2	226-3900	res net, 390ohm, 10pin, SMD	6	R1, R2, R3, R6, R7, R14
....2	270-4111	IC,DUAL,SOLID STATE RELAY,8-PIN,DIP	8	U5, U6, U7, U8, U9, U10, U11, U12
....2	411-0223	EMI FILTER, 1000pF, SMD	6	C1, C2, C3, C4, C5, C6
....2	417-0173	CONN,PCB,40-PIN,609-4037	1	JP5
....2	417-1550-008	CONN,HEADER,RT.ANGLE,8-PIN,3.81MM SPACING,PCB MOUNT	8	JP1, JP2, JP3, PJ4, JP6, JP7, JP8, JP9
....2	519-0553	PCB,MACH,TERMINAL STRIP I/O INTERFACE,FM-IBOC & AM-IBOC DSG	1	
....2	540-0505	1.5W Modular DC/DC Converter	2	U17, U18
....2	540-1055	DC/DC Converter SMD	1	U16
..1	919-0557-001	ASSY, PCB, FRONT PANEL LED, FM-IBOC & AM-IBOC, DSG	1	
....2	103-4993	RES,499 OHM,1/4W,1%,METAL	2	R1, R2
....2	323-9224	IND,LED,GRN,521-9270	2	LED1, LED2
....2	340-0004	SW,JUMPER PROGRAMMABLE	1	P2
....2	417-4004	CONN,HEADER,2 PIN	2	J2, J3
....2	418-0255	CONN,MALE,4PIN	1	J1
....2	441-0009	SPR,PHENOLIC 1/4RND X 1/2 #6	2	
....2	519-0557	PCB, MACH, FRONT PANEL LED, DTG DIGITAL EXCITER	1	
..1	919-0558	PCB, ASSY, LCD POWER, FM-IBOC & AM-IBOC, DSG	1	
....2	020-4773	CAP,LYTIC,47UF,35V,STDUP	1	C1
....2	103-4741	RES,4.75K OHM,1/4W,1%,METAL	1	R1
....2	224-0200	IC, TWO TUBE DC TO AC CONVERTER, +12 VDC INPUT	1	U1
....2	417-0070	CONN,HEADER 4 PIN	1	J1
....2	431-0280	CONN,2PIN,HV,8MM,RT ANGLE,SMD	2	J2, J3
....2	519-0558	PCB, MACH, LCD POWER, FM-IBOC & AM-IBOC, DSG	1	
..1	949-0541-003	ASSY,WIRE HARNESS,FSi/ASi,MB3 (SBCM)	1	
....2	402-0051	TY-RAP, W/FLAG	36	
....2	417-0053	SKT,CONN 641294-1 AMP	3	
....2	417-0138	HSNG,MOD IV 4 POS 87499-7 AMP	2	
....2	417-0142	PIN,.050 DIA 26-22 745254-3	5	
....2	417-0143	SKT,PIN .050 26-22 745253-3	7	
....2	417-0165	HSNG,5POS MOD IV S.ROW 87499-9	1	
....2	417-0224	KEYING PLUG MOD IV 87077 AMP	4	
....2	417-0286	PLUG,2.5 MM FEMALE	1	

BOM LEVEL	PART NO.	DESCRIPTION	QTY	REF. DES.
....2	417-0323	CONNECTOR,TNC BULKHEAD,FOR RG316/U COAXIAL CABLE	1	
....2	417-0402	CONN,20 PIN,DUAL ROW,MINI-FIT,FEMALE	1	
....2	417-0405	CONTACT, CRIMP, 18-24 AWG, FEM	20	
....2	417-0407	CONTACT, MALE, 18-24 AWG, CRIMP	20	
....2	417-0408	CONN, 20 PIN, MALE,	1	
....2	417-0413	Contact FEM 22-28 AWG XHP Series	3	
....2	417-0414	Conn, FEM, 4 Pin	1	
....2	417-0415	Conn, FEM, 5 Pin	1	
....2	417-0900	PLUG,9 PIN STD 205204-3 AMP	1	
....2	417-0901	RCPT,9 PIN STD 205203-3 AMP	2	
....2	417-1003	SKT,CONN 10PIN ANSLEY 622-1030	6	
....2	417-1702	RIGHT ANGLE CRIMP TYPE PLUG,SMB,50 OHM	2	
....2	417-2011	CONN,SOCKET,10 POS, .100 POLARIZED WIREMOUNT"	1	
....2	417-2020	CONN,SOCKET,20 POS, .100 POLARIZED WIREMOUNT"	1	
....2	417-2021	CONN,SOCKET,24 POS, .100 POLARIZED WIREMOUNT"	1	
....2	417-2560	CONN,MINI-DIN,6-POS,SOCKET,PANEL MOUNT	2	
....2	417-2570	CONN,MINI-DIN,6-POS,IN-LINE PLUG	2	
....2	417-2814	PLUG, 8 POS ETHERNET 10BaseT	6	
....2	417-2815	CONN, 9-PIN, FEMALE, IDC, Dsub	2	
....2	417-8030	CONN,PLUG,RT ANG,SMA,HEX CRIMP	2	
....2	417-8766	CONTACT,CRIMP,MOD-IV 87809-1	8	
....2	417-8980	Male Crimp Terminal	4	
....2	417-8981	Male Crimp Housing	1	
....2	418-0034	PLUG,BNC DUAL CRIMP 1-227079-6	1	
....2	418-0240	PLUG,FEM,4PIN	1	
....2	418-4001	CONN,RIBBON CBL,40COND	2	
....2	600-0002	RIBBON CBL,3580-10 ALPHA	6.916	
....2	600-0040	CBL,40COND,28GA,100 ANSLEY	1.333	
....2	601-2209	WIRE,AWG22,19/34 WHT	48.853	
....2	602-2202	WIRE,TW,AWG22,PVC INS,BLK/RED	4.562	
....2	603-2200	WIRE,TW,AWG22,INS,RED-YEL-BLU	1.666	
....2	610-5096	CBL,6 CONDUCTOR,24 AWG,SHIELDED,PVC	3.1	
....2	610-8723	CBL,SH 4 COND #22 ST 8723 BELD	5.166	
....2	621-1359	CBL,COAX,RG316/U,50 OHM	7.166	
....2	622-1245	CBL,ETHERNET,10BASET,CAT5	5.874	
..1	949-0541-300	ASSY,CABLE,ADAPT PWR TO 959-4167-100	1	
....2	417-4303	CONN, CRIMP TERMINAL, FEMALE, 20-24 AWG	2	
....2	417-4364	CONN, RECEPTACLE 2 POS, HEADERS & WIRE HOUSINGS	1	
....2	418-0712	CONN, DC POWER 2.5MM ROUND W/NUT	1	
....2	601-2209	WIRE,AWG22,19/34 WHT	1.167	
....2	611-0938	TUBE, HEAT SHINK, 3/32, BLACK"	0.083	
....2	611-5000	TUB,HT SHK 1/2	0.062	
..1	949-0546	ASSY,CABLE,FAN,FSi/ASi (SBCM)	1	



BOM LEVEL	PART NO.	DESCRIPTION	QTY	REF. DES.
....2	417-8500	PLUG AND CORD ET,AM500 FAN	1	
....2	417-8980	Male Crimp Terminal	2	
....2	417-8981	Male Crimp Housing	1	
..1	949-0548	ASSY, HARN, KIT, AM-IBOC ADD ON (SBCM)	1	
....2	417-0138	HSNG,MOD IV 4 POS 87499-7 AMP	1	
....2	417-8766	CONTACT,CRIMP,MOD-IV 87809-1	2	
....2	417-8980	Male Crimp Terminal	2	
....2	417-8981	Male Crimp Housing	1	
....2	602-2202	WIRE,TW,AWG22,PVC INS,BLK/RED	1	
..1	949-4263-100	VGA CABLE FOR 959-4167-100	1	
..1	959-0252-001	3M SC4 TOUCH SCREEN CONTROLLER BD	1	
..1	959-0376-001	GPS,TIME & FREQUENCY MODULE,FSi/ASi	1	
..1	959-0377-001	MEMORY MODULE,512MB,184-PIN DDR SDRAM DIMM,FSi/ASi	1	
..1	959-0378	MODEM CARD,INTERNAL,56K,PCI,FM-IBOC & AM-IBOC DSG	1	
..1	959-0379-001	AUDIO CARD,2xAES/EBU I/O,ASi/FSi/XPi	1	
..1	959-0382-003	PS,SWITCHING PFC 485W UNIV. IN, FSi/ASi/XPi (NOTE)	1	
..1	959-0383-003	MOTHERBOARD,ATX,800MHz FSB SUPPORT,FSi/ASi/XPi	1	
..1	959-0384-001	HARD DRIVE,80GB,7200 RPM,ULTRA ATA/100,FSi/ASi,MB2	1	
..1	959-0385	SERIAL PORT CARD,PCI,FM-IBOC & AM-IBOC DSG	1	
..1	959-0386	CD-ROM DRIVE,SLIM 24X,INTERNAL MOUNT,BLACK,FM/AM-IBOC DSG	1	
..1	959-0386-001	ADAPTER,SLIMLINE CD TO 40-PIN IDE CONVERTER BOARD	1	
..1	959-0387	KIT,OSD ROTARY	1	
..1	959-4167-100	ALR-1400 FLAT PANEL INTERFACE CONTROLLER	1	
..1	979-0542-AM4	KIT,BINDER AND MANUAL,ASi	1	
....2	597-0542-003	INSTRUCTION MANUAL, ASI 10 GENERATOR, AM-IBOC	1	
....2	598-0010-001	BINDER,1 IN, BLUE,W CD POCKET	1	
....2	979-6025-433	KIT,SOFTWARE CDROM,ASI10,V4.3.2P1	1	
.....3	579-0007	CD-CASE CLEAR PLASTIC	1	
.....3	597-0125-002	APPLICATION GUIDE,ASI-10 SOFTWARE UPGRADE	1	
.....3	701-0018	ANTISTATIC BAG ZIPLOC 9X12 4M	1	
.....3	979-6025-AM9	CDROM,ASI10,V4.3.2p1	1	
..1	979-0544	KIT, ASi-10 INSTALLATION, AM-IBOC, DSG	1	
....2	003-1066	CAP,CER,MNLY,.1uF,50V,10% *NOTE*	1	
....2	417-0910	KIT,BACKSHELL FOR 9-PIN D CONN	1	
....2	418-1550-008	CONN,PLUG,8-PIN,CAGE CLAMP,3.81MM SPACING	7	
....2	420-0007	SCREW,12-24 X 3/4,NATURAL SST,TRUSS HD, PHILLIPS DRIVE"	4	
....2	420-0710	SCR,10-32 X 5/8,NATURAL SST,TRUSS HD,PHILLIPS DRIVE"	4	
....2	421-0002	12-24 SPEED NUT (NOTE)	4	

BOM LEVEL	PART NO.	DESCRIPTION	QTY	REF. DES.
....2	550-112	Connector, D-Sub 9 pin male Keltron DN-09PYSH-G	1	
....2	608-1800	CBL,SHLD,AES/EBU,BELDEN 1800B (N)	50	
....2	622-8451	WIRE,BELD 8451,SHIELD,1PR	10	
....2	682-0001	CORD LINE,3 COND,DETACH 7.5FT	1	
....2	682-0003	CORD,PWR EUROPEAN RIGHT ANGLE, 6'	1	
....2	701-0019	ANTISTATIC ZIPLOC BAG 13X18 4M	1	
....2	829-4216	PLUG,FEM XLR, A3F (XLR-3-11C)	5	
....2	829-4217	PLUG,MALE XLR, A3M (XLR-3-12C)	5	
....2	949-0542	ASSY,CABLE,GPS DATA IN/OUT,FSi/ASi (SBCM)	1	
.....3	402-0051	TY-RAP, W/FLAG	1	
.....3	417-0142	PIN,.050 DIA 26-22 745254-3	4	
.....3	417-0143	SKT,PIN .050 26-22 745253-3	4	
.....3	417-0900	PLUG,9 PIN STD 205204-3 AMP	1	
.....3	417-0901	RCPT,9 PIN STD 205203-3 AMP	1	
.....3	417-0910	KIT,BACKSHELL FOR 9-PIN D CONN	2	
.....3	610-8723	CBL,SH 4 COND #22 ST 8723 BELD	0.666	
....2	949-0543	ASSY,CABLE,1PPS IN/OUT,FSi/ASi (SBCM)	1	
.....3	402-0051	TY-RAP, W/FLAG	1	
.....3	418-0034	PLUG,BNC DUAL CRIMP 1-227079-6	2	
.....3	621-1359	CBL,COAX,RG316/U,50 OHM	0.333	
....2	949-0547	HARN, KIT AM-IBOC (SBCM)	1	
.....3	410-0065	LUG,TERM #6 RING CRIMP #22 AWG	1	
.....3	417-0053	SKT,CONN 641294-1 AMP	5	
.....3	417-2814	PLUG, 8 POS ETHERNET 10BaseT	1	
.....3	418-0034	PLUG,BNC DUAL CRIMP 1-227079-6	4	
.....3	418-0670	HOUSING,CONN,6PIN FEM	1	
.....3	418-1550-002	CONN,PLUG,2-PIN,CAGE CLAMP,3.81MM SPACING	1	
.....3	418-1550-008	CONN,PLUG,8-PIN,CAGE CLAMP,3.81MM SPACING	1	
.....3	602-2202	WIRE,TW,AWG22,PVC INS,BLK/RED	1.43	
.....3	611-0061	TUB,HT SHK CLEAR 3/64	0.383	
.....3	621-1359	CBL,COAX,RG316/U,50 OHM	14.66	
.....3	622-1245	CBL,ETHERNET,10BASET,CAT5	1.34	
.....3	622-8451	WIRE,BELD 8451,SHIELD,1PR	27.6	
.....3	829-4216	PLUG,FEM XLR, A3F (XLR-3-11C)	1	
....2	957-0100	KIT, AM XMTER IBOC CONVERSION	1	
.....3	422-6107	SCREW,SEMS 6-32 X 7/16 PAN PH.ST."	2	
.....3	441-0152	STOFF,#6-32,MALE/FEM 1/4	2	
.....3	597-0125-001	APPLICATION GUIDE,AM TX/ASI,SETUP FOR HD OPERATION	1	
.....3	597-0501-001	APPLICATION GUIDE,AM TRANSMITTER C90 REPLACEMENT	1	
.....3	919-0560	PCB, ASSY, IBOC BYPASS	1	
.....4	003-1066	CAP,CER,MNLY,.1uF,50V,10% *NOTE*	2	C2, C3
.....4	003-4743	CAP,CER MNLY,.47uF,50V,10%	1	C1
.....4	042-3912	CAP,MICA,39PF,500V,5%	2	C4, C5
.....4	100-1041	RES,1K OHM,1/4W,1%	2	R2, R5
.....4	103-1007	RES,1 MEG OHM,1/4W,1%,METAL	1	R1
.....4	103-4741	RES,4.75K OHM,1/4W,1%,METAL	2	R3, R4



BOM LEVEL	PART NO.	DESCRIPTION	QTY	REF. DES.
.....4	178-5045	RES,TRMR,5K,20T,VERT	1	R6
.....4	203-4148	DIODE,1N4148	4	D1, D2, D3, D4
.....4	221-4132	IC,74HC132N QUAD SCHMITT NAND	1	U1
.....4	417-0259	CONN, BNC PCB MOUNT	2	J1, J3
.....4	417-0677	CONN,PCB MT,6PIN MALE	1	J2
.....4	519-0560	PCB, MACH, AM IBOC BYPASS	1	



8 RF TECHNICAL SERVICES CONTACT INFORMATION

RF Technical Service -

Telephone: **(217) 224-9617**

E-Mail: rfservice@bdcast.com

Fax: **(217) 224-6528**

web: www.bdcast.com



9 Drawings

9.1 Introduction

The following text provides assembly drawings, schematic diagrams, and additional information as indexed below for the ASI AM IBOC Digital Signal Generator.

FIGURE	TITLE	NUMBER
9-1	ASI 10 REAR PANEL CONNECTOR DESCRIPTIONS	597-0541-81
9-2	ASI 10 REMOTE CONTROL INPUTS/OUTPUTS	597-0541-82
9-4	IBOC CONNECTION DIAGRAM, BEI A-SERIES AM TRANSMITTERS	597-0541-77
9-5	IBOC CONNECTION DIAGRAM, BEI E-SERIES AM TRANSMITTERS	597-0541-78
9-6	ASI 10 REAR PANEL	597-0541-79
9-7	SCHEMATIC DIAGRAM, DIGITAL UPCONVERTER, CIRCUIT BOARD	SD919-0548-002
9-8	ASSEMBLY DIAGRAM, DIGITAL UPCONVERTER CIRCUIT BOARD	AD919-0548-002
9-9	SCHEMATIC DIAGRAM, STATION INTERFACE CIRCUIT BOARD	SD919-0549
9-10	ASSEMBLY DIAGRAM, STATION INTERFACE CIRCUIT BOARD	AD919-0549
9-11	SCHEMATIC DIAGRAM, AM SAMPLE RATE CONVERTER CIRCUIT BOARD	SD919-0550
9-12	ASSEMBLY DIAGRAM, AM SAMPLE RATE CONVERTER CIRCUIT BOARD	AD919-0550
9-13	SCHEMATIC DIAGRAM, XLR-TO-BNC I/O INTERFACE CIRCUIT BOARD	SD919-0551
9-14	ASSEMBLY DIAGRAM, AM SAMPLE RATE XLR-TO-BNC I/O INTERFACE CIRCUIT BOARD	AB919-0551
9-15	SCHEMATIC DIAGRAM, RJ-45/USB/DB-9 I/O INTERFACE CIRCUIT BOARD	SD919-0552
9-16	ASSEMBLY DIAGRAM, RJ-45/USB/DB-9 I/O INTERFACE CIRCUIT BOARD	AC919-0552
9-17	SCHEMATIC DIAGRAM, TERMINAL STRIP I/O INTERFACE CIRCUIT BOARD	SD919-0553
9-18	ASSEMBLY DIAGRAM, TERMINAL STRIP I/O INTERFACE CIRCUIT BOARD	AC919-0553
9-19	SCHEMATIC DIAGRAM, FRONT PANEL LED CIRCUIT BOARD	SA919-0557-001
9-20	ASSEMBLY DIAGRAM, FRONT PANEL LED CIRCUIT BOARD	AA919-0557-001
9-21	SCHEMATIC DIAGRAM, LCD POWER CIRCUIT BOARD	SA919-0558
9-22	ASSEMBLY DIAGRAM, LCD POWER CIRCUIT BOARD	AA919-0558

ASI REAR-PANEL CONNECTOR DESCRIPTIONS – 597–0541–81.

ASI REAR-PANEL CONNECTOR DESCRIPTIONS (Sheet 1 of 2)			
Function	Input/Output	Description	Connector
1 PPS IN	Input	TTL level, 50 ohm	BNC Female
10 MHz OUT	Output	0 dBm, 50 ohm	BNC Female
SPARE 1	Input/Output	Not Connected	BNC Female
PHASE	Output (50 Ohm) Phase	500 – 1770 kHz	BNC Female
AM OUT	Output (50 Ohm)	–15 dBm FM – 10.7 MHz –25 dBm AM – 500 to 1770 kHz	BNC Female
GPS DATA IN	Input	RS–232	DB9 Male
GPS DATA OUT	Output	RS–232. The GPS data output provides data to the ASI via the GPS DATA IN connector in serial format at 19200 8 N 1. Upon startup, the GPS outputs a packet of information that includes the type and status of the device. The GPS can then be controlled by the ASI. Once the GPS is locked and stable, it provides timing and position information in one second bursts.	DB9 Female
IBOC DATA	Input	RS–232	DB9 Male
AM FM AES IN	Input	AES/EBU Audio	XLR Female
IBOC AES IN	Input	AES/EBU Audio	XLR Female
AM FM AES OUT	Output	AES/EBU Audio	XLR Male
IBOC MONITOR	Output	AES/EBU Audio	XLR Male
IBOC/AM MAG OUT	Output	Balanced Analog Audio 600 ohm pin 5+ ,4 –	RJ45 Female
Phase	Output	RS422 100 ohm	RJ45 Female
LVDS TO IBOC DATA	Output	LVDS ieee1596.3 BaseBand Digital I/Q data 100 ohm Pin 1=FS+, 2=FS–, 4=CLK+, 5=CLK– 7=Data+, 8=Data –	RJ45 Female
I/Q	Output	BaseBand analog I/Q 100 ohm Pin 5=I+, 4=I–, 3=Q+, 6=Q–	RJ45 Female
SPARE 2	Input/Output	Not Connected.	RJ45 Female
ETHERNET	Input/Output	100 MHz Network Connection.	RJ45 Female
MODEM	Input/Output	Two Wire Telephony connection.	RJ11 Female
USB	Input/Output	USB.	Dual USB Female
MOUSE	Input	PS2 Compatible.	PS2
KEYBOARD	Input	PS2 Compatible.	PS2
INPUTS 1 THRU 14	Input	Static Input+ 390 ohm pullup to 5V, All – tied together.	Phoenix 8 pin Female
INPUT15	Input	Static Input+ 390 ohm pullup to 5V, All – tied together. Short + to – for 3 seconds for system reset.	Phoenix 8 pin Female
INPUT 16	Input	Static Input+ 390 ohm pullup to 5V, All – tied together. Short + to – for 3 sec's for a system pwr down repeat for a pwr up.	Phoenix 8 pin Female

ASI REAR-PANEL CONNECTOR DESCRIPTIONS (Sheet 2 of 2)			
OUTPUT 1 THRU 12	Output	Static Output+ 390 ohm pullup to 5V, All – tied together.	Phoenix 8 pin Female
OUTPUT 13 AND 14	Output	Bypass A. Static Outputs SS relay from + to –. Connected to AUDIO BYPASS.	Phoenix 8 pin Female
OUTPUT 15 AND 16	Output	Static Outputs SS relay from + to –.	Phoenix 8 pin Female
AC Power Input	Input	115Vac @ 13 Amps or 230Vac @ 8 Amps	IEC AC input
GPS ANT IN	Input	Power is supplied to the antenna via the center conductor of the coaxial cable. This connection must be made with a single cable and not through any other devices such as an amplifier or splitter/combiner.	TNC
AUDIO BYPASS	Input	Pins 1–2 are connected to pins 13 +/- of the audio bypass A output connector. This provides exciter control of the Audio switching relay.	Phoenix 2 Position Female
STUDIO AES IN	Input	The source (unprocessed) AES signal is supplied via this connector. The AES signal is rate converted to the 44.1kHz sample rate and synchronized to system timing. After the signal is rate converted, it is distributed to 2 XLR males connectors labeled IBOC AES OUT and AM AES OUT.	XLR Female
IBOC AES OUT	Output	See STUDIO AES IN.	XLR Male
AM AES OUT	Output	See STUDIO AES IN.	XLR Male
IBOC/AM MAG IN	Input	An Input to Audio switch A. When the ASI is operating normally, the magnitude signal from the IBOC/AM MAG IN connector is routed to the transmitter via the AM TX AUDIO OUT connector. When an ASI failure occurs, the signal from the AM AUDIO IN connector is routed to the transmitter via the AM TX AUDIO OUT connector.	RJ45
AM AUDIO IN	Input	An Input to Audio switch A. When the ASI is operating normally, the magnitude signal from the IBOC/AM MAG IN connector is routed to the transmitter via the AM TX AUDIO OUT connector. When an ASI failure occurs, the signal from the AM AUDIO IN connector is routed to the transmitter via the AM TX AUDIO OUT connector.	XLR Female
1PPS OUT	Output	TTL level, one pulse per second signals from the GPS. Pulse width is defaulted to 2ms.	BNC
44.1 kHz WORDCLOCK	Output	Output supplies the <i>WORD</i> clock to external devices for synchronization purposes. TTL compatible and stable into 50 ohms.	BNC
10 MHZ OUT	Output	GPS 10MHz sine wave @+3dBm into 50 ohms.	BNC


ASI REMOTE CONTROL INPUTS/OUTPUTS – 597–0541–82.

ASI REMOTE CONTROL INPUTS		
INPUT #	INPUT NAME	SIGNALING METHOD
1	Digital Carrier On	high-to-low/negative edge
2	Digital Carrier Off	high-to-low/negative edge
3	Audio Ramp Up To Delay	high-to-low/negative edge
4	Audio Ramp Down From Delay	high-to-low/negative edge
5	Audio Delay Increase	high-to-low/negative edge
6	Audio Delay Decrease	high-to-low/negative edge
7	Audio-A Bypass On	high-to-low/negative edge
8	Audio-A Bypass Off	high-to-low/negative edge
9	Audio-B Bypass On	high-to-low/negative edge
10	Audio-B Bypass Off	high-to-low/negative edge
11	Day	high-to-low/negative edge
12	Night	high-to-low/negative edge
13	—	—
14	System Shutdown	high-to-low/negative edge
15	System Power On/Off Toggle	hold low for at least 2 seconds, then high
16	System Reset	hold low for at least 2 seconds, then high


Note: "Low" or "Low Voltage" refers to a nominal TTL low logic level (0 volts).
 "High" or "High Voltage" refers to a nominal TTL high logic level (+5 volts).


ASI REMOTE CONTROL OUTPUTS			
OUTPUT #	OUTPUT NAME	LOW VOLTAGE OR CLOSED RELAY	HIGH VOLTAGE OR OPEN RELAY
1	Digital Carrier On/Off Status	Digital Carrier Off	Digital Carrier On
2	Audio Ramp Up/Down Status	Ramping Not Done	Ramping Done
3	Audio Delay In/Decrease Status	In/Decrease Not Done	In/Decrease Done
4	Audio-A Bypass Status	Audio-A Bypass Off	Audio-A Bypass On
5	Audio-B Bypass Status	Audio-B Bypass Off	Audio-B Bypass On
6	Day/Night Status	Night	Day
7	System Shutdown Status	Shutdown Not Done	Shutdown Done
8	System Operational Status	System Not Operational	System Operational
9	System Alarm Status	No System Alarm	System Alarm
10	—	—	—
11	—	—	—
12	—	—	—
13	Audio-A Bypass Status (relay)	Audio-A Bypass Off	Audio-A Bypass On
14	Audio-B Bypass Status (relay)	Audio-B Bypass Off	Audio-B Bypass On
15	—	—	—
16	System Operational Status (relay)	System Operational	System Not Operational

Note: "Low" or "Low Voltage" refers to a nominal TTL low logic level (0 volts).
 "High" or "High Voltage" refers to a nominal TTL high logic level (+5 volts).





**BEI AM A-SERIES SYSTEM CONNECTION
 DIAGRAM
 597-0541-77**





ASI-10 SIGNAL GENERATOR








COPYRIGHT © 2005 BROADCAST ELECTRONICS, INC.

COPYRIGHT © 2005 BROADCAST ELECTRONICS, INC.

<small>PROPRIETARY RIGHTS are included in information disclosed herein. This information is submitted in confidence and neither this document nor the information disclosed herein shall be reproduced or transmitted to other documents or used or disclosed to others for manufacturing or for any other purpose except as specifically authorized in writing by BROADCAST ELECTRONICS, INC.</small>	DWN. BY 2-22-05	MATERIAL	BROADCAST ELECTRONICS INC. 4100 N. 24TH ST., P.O. BOX 3606 QUINCY, IL 62305 217/224-0600 TELEX 250142 CABLE BROADCAST FAX 217/224-0607
	DESIGNER(S)	FINISH	
	PROJ. LEADER	SEE DWG RA502-0000	
	MFG.	NEXT ASSY.	
TOLERANCE (DECIMAL) U.S.S. .x ± .030 .xxx ± .005 .xx ± .015 ANGLES ± 1°	TITLE OVERALL WIRING DIAGRAM FSI-10/ASI-10		TYPE SIZE DWG. NO. REV S D 909-6025-MB3 A 909-6026-MB3
MODEL FSI/ASI		SCALE NTS	SHEET 2 OF 2








REVISIONS					
REV	DATE	DESCRIPTION	DRAFTER	APPROVED	ECN
1	2-3-04	PROTOTYPE RELEASE	KT		----
2	9-29-04	ADDED R18, U41, C251, C252	KT		----
4	1-21-05	CHG'D C251 TO 0.1uF TO MATCH BOM	KT		----
8	11-17-05	CHG'D C23,24,26,30,31,51 TO (070-6864)	JTB		11350

TEST HEADER

- 1 J15
- 2 J15
- 3 J15
- 4 J15
- 5 J15
- 6 J15
- 7 J15
- 8 J15
- 9 J15
- 10 J15
- 11 J15
- 12 J15
- 13 J15
- 14 J15
- 15 J15
- 16 J15
- 17 J15
- 18 J15
- 19 J15
- 20 J15
- 21 J15
- 22 J15
- 23 J15
- 24 J15
- 25 J15
- 26 J15
- 27 J15
- 28 J15
- 29 J15
- 30 J15
- 31 J15
- 32 J15
- 33 J15
- 34 J15
- 35 J15
- 36 J15
- 37 J15
- 38 J15
- 39 J15
- 40 J15

PROPRIETARY RIGHTS are included in information disclosed herein. This information is submitted in confidence and neither this document nor the information disclosed herein shall be reproduced or transferred to other documents or used or disclosed to others for manufacturing or for any other purpose except as specifically authorized in writing by iBiquity Digital Corporation.					
DWN. BY KT 1-14-04		MATERIAL SEE BOM 919-0548-002		iBiquity Digital 8865 Stanford Boulevard, Suite 202, Columbia, MD 21045 (410) 872-1530 FAX (410) 872-1531	
DESIGNER(S)		FINISH		TITLE DIGITAL UPCONVERTOR II	
PROJ. LEADER		NEXT ASSY.		TYPE S	
MFG.				SIZE DWG. NO. 919-0548-002	
TOLERANCE (DECIMAL) U.O.S. .x ± .030 .xxx ± .005 .xx ± .015 ANGLES ± 1°				MODEL NNNN	
				SCALE NONE	
				SHEET 4 OF 12	





REVISIONS					
REV	DATE	DESCRIPTION	DRAFTER	APPROVED	ECN
1	2-3-04	PROTOTYPE RELEASE	KT		----
8	11-17-05	CHG'D C23,24,26,30,31,51 TO (070-6864)	JTB		11350


COPYRIGHT © 2004 iBiquity Digital


COPYRIGHT © 2004 iBiquity Digital


PROPRIETARY RIGHTS are included in information disclosed herein. This information is submitted in confidence and neither this document nor the information disclosed herein shall be reproduced or transferred to other documents or used or disclosed to others for manufacturing or for any other purpose except as specifically authorized in writing by iBiquity Digital Corporation.	DWN. BY KT 1-14-04	MATERIAL SEE BOM 919-0548-002	iBiquity Digital 8865 Stanford Boulevard, Suite 202, Columbia, MD 21045 (410) 872-1530 FAX (410) 872-1531		
	DESIGNER(S)	FINISH	TITLE DIGITAL UPCONVERTOR II		
	PROJ. LEADER		TYPE S	SIZE DWG. NO. 919-0548-002	REV B
	MFG.	NEXT ASSY.	MODEL NNNN	SCALE NONE	SHEET 5 OF 12
















REVISIONS					
REV	DATE	DESCRIPTION	DRAFTER	APPROVED	ECN
1	2-3-04	PROTOTYPE RELEASE	KT		----
2	8-25-04	CHGD U3,U4,R11,R56,R58; DEL R46,R50; CHGD PWR TO U19	KT		----
3	12-15-04	CHGD C11,C15,C89,C92,C93,R11,R12,R44,U3; ADD R100,R101	KT		----
4	1-21-05	CHGD R100 & R101 TO 511 TO MATCH BOM	KT		----
B	11-17-05	CHG'D C23,24,26,30,31,51 TO (070-5864)	JTB		11350

COPYRIGHT © 2004 iBiquity Digital					
PROPRIETARY RIGHTS are included in information disclosed herein. This information is submitted in confidence and neither this document nor the information disclosed herein shall be reproduced or transferred to other documents or used or disclosed to others for manufacturing or for any other purpose except as specifically authorized in writing by iBiquity Digital Corporation.			DWN. BY KT 1-14-04 DESIGNER(S) PROJ. LEADER MFG.		
TOLERANCE (DECIMAL) U.O.S. .xx ± .030 .xxx ± .005 .xx ± .015 ANGLES ± 1°			MATERIAL SEE BOM 919-0548-002 FINISH NEXT ASSY.		
			iBiquity Digital 8865 Stanford Boulevard, Suite 202, Columbia, MD 21045 (410) 872-1530 FAX (410) 872-1531		
			TITLE DIGITAL UPCONVERTOR II		
			TYPE S		
			SIZE 919-0548-002		
			REV B		
			MODEL NNNN		
			SCALE NONE		
			SHEET 12 OF 12		





REVISIONS				
REV	DATE	DESCRIPTION	DRAFTER	APPROVED
A	10-31-02	REDRAWN IN P-CAD	KT	DK
C	8-10-05	SEE SHEET 2	KT	DK


COPYRIGHT © 2002 BROADCAST ELECTRONICS, INC.

PROPRIETARY RIGHTS are included in information disclosed herein. This information is submitted in confidence and neither this document nor the information disclosed herein shall be reproduced or transferred to other documents or used or disclosed to others for manufacturing or for any other purpose except as specifically authorized in writing by BROADCAST ELECTRONICS, INC.

DWN. BY
KT 10-31-02
DESIGNER(S)
PROJ. LEADER
MFG.


MATERIAL
SEE BOM
919-0549
FINISH
NEXT ASSY.


BROADCAST ELECTRONICS, INC. 4100 N. 24TH ST., P.O. BOX 3606 QUINCY, IL. 62305 217/224-9600 FAX 217/224-9607		
TITLE STATION INTERFACE		
TYPE S	SIZE D	DWG. NO. 919-0549
MODEL NNNN	SCALE NONE	SHEET 1 OF 2



REVISIONS				
REV	DATE	DESCRIPTION	DRAFTER	APPROVED
A	10-31-02	REDRAWN IN P-CAD	KT	DK
B	2-9-05	CHGD J133	KT	DK
C	8-10-05	ADDED NOTES FOR P3	KT	DK

PROPRIETARY RIGHTS are included in information disclosed herein. This information is submitted in confidence and neither this document nor the information disclosed herein shall be reproduced or transferred to other documents or used or disclosed to others for manufacturing or for any other purpose except as specifically authorized in writing by BROADCAST ELECTRONICS, INC.		OWN. BY KT 10-31-02 DESIGNER(S)	MATERIAL SEE BOM 919-0549	BROADCAST ELECTRONICS, INC. 4100 N. 24TH ST., P.O. BOX 3606 QUINCY, IL. 62305 217/224-9600 FAX 217/224-9607	
TOLERANCE (DECIMAL) U.O.S. .x ± .030 .xxx ± .005 .xx ± .015 ANGLES ± 1°		PROJ. LEADER	FINISH	TITLE STATION INTERFACE	
MFG.		NEXT ASSY.		SHEET 2 OF 2	





REVISIONS							
REV	DATE	DESCRIPTION			DRAFTER	APPROVED	ECN
1	10-7-02	PROTOTYPE RELEASE			KT		----
A	11-15-02	TIED U5-OUT NET TO +5V; MODEL RELEASE			KT	DK	
B	1-28-03	CHGD C25,C26,R26; ADDED C53,C54; FIXED J4			KT	DK	10877
C	12-29-04	CHGD R26 TO 3.01K			KT	DK	11215

- NOTES:
1. ALL RESISTORS IN OHMS; 1/10W, 1% UNLESS OTHERWISE SPECIFIED.
 2. LAST COMPONENT USED: C54,D4,DS2,J16, K1,L5,P15,Q5,R84,T3,TP11,U14
 3. COMPONENTS NOT USED: C17-C21, C38-C42,U5,R31,R53-R56,R63,R65, R59,TP1-TP8,U8,P1-P11
 4. SEE ASSEMBLY: AC919-0550
 5. * INDICATES NOT PLACED: R31,R51,R52,R67,C25,U9 C33,C35,C36,C37,R12
 6. # DENOTES XP1 FUNCTION

PROPRIETARY RIGHTS are included in information disclosed herein. This information is submitted in confidence and neither this document nor the information disclosed herein shall be reproduced or transferred to other documents or used or disclosed to others for manufacturing or for any other purpose except as specifically authorized in writing by BROADCAST ELECTRONICS, INC.

DRAWN BY: KT 8-2-02
DESIGNER(S):
PROJ. LEADER
RFG.

MATERIAL: SEE BOM 919-0550
FINISH:
NEXT ASSY.

4100 N. 24TH ST., P.O. BOX 3606 QUINCY, IL. 62305
217/224-9600 FAX 217/224-9607


TITLE: SRC CARD
TYPE: S D
SIZE: 1/2
Dwg. NO.: 919-0550
REV: G

MODEL: RS1/XP1
SCALE: NONE
SHEET: 1 OF 2


G	4-20-07	CHG'D R44 (102-5112) MADE FL1-FL12 (102-0000)	JTB	11529
F	6-23-06	CHG'D U7 TO(216-4111);ADD L3,L4(366-0010-001)	JTB	11451
E	5-17-05	CHGD NOTES: SEE SHEET 2 ALSO	KT	11289
D	2-14-05	CHGD NOTES: SEE SHEET 2 ALSO	KT	11259

COPYRIGHT © 2002 BROADCAST ELECTRONICS, INC.

COPYRIGHT © 2002 BROADCAST ELECTRONICS, INC.




REVISIONS					
REV	DATE	DESCRIPTION	DRAFTER	APPROVED	ECN
1	9-26-02	PROTOTYPE RELEASE	KT		----
A	11-15-02	FIXED L1; DEL C41 & C42, CHGD NETS: MODEL BUILD	KT	DK	----
B	1-29-03	ADDED R70-R72,C53,C54; CHGD C26,R26; MARKED C25 AS NOT PLACED; FIXED J4 & J10	KT	DK	10877
C	12-29-04	CHGD R26 TO 102-3011	KT	DK	11215
D	2-15-05	ADDED J12-J15,P12-P15; MADE BOARD 0.300" WIDER	KT	DK	11259
E	5-18-05	ADDED C31-C37,J16,R12,R27,R31,R44,U7,U9	KT	DK	11289
F	6-23-06	CHG'D U7 TO (216-4111);ADD L3,L4(366-0010-001)	JTB	DK	11451
G	4-20-07	CHG'D R44 (102-5112)CHG'D FL1-FL12 TO(102-0000)	JTB		11529





NOTES:

- 1) * INDICATES PART NOT PLACED (C25,C33,C35-C37,R12,R51,R52,R67,U9)
- 2) INSTALL SOFTWARE 979-0550-U6 VER 1.0, BEFORE ASSEMBLY
- 3) INSTALL R72 ON SOLDER SIDE BEFORE INSTALLING J10.



PROPRIETARY RIGHTS are included in information disclosed herein. This information is submitted in confidence and neither this document nor the information disclosed herein shall be reproduced or transferred to other documents or used or disclosed to others for manufacturing or for any other purpose except as specifically authorized in writing by BROADCAST ELECTRONICS, INC.	DWN. BY KT 8-19-02	MATERIAL SEE BOM 919-0550	<div>BE® BROADCAST ELECTRONICS INC.</div> <div>4100 N. 24TH ST. P.O.BOX 3606 QUINCY,IL. 62305 217/224-9600 FAX 217/224-9607</div>			
	DESIGNER(S)					
	PROJ. LEADER	FINISH	TITLE SRC CARD			
	MFG.					
TOLERANCE (DECIMAL) U.O.S. .X ± .030 .XXX ± .005 .XX ± .015 ANGLES + 1°			TYPE A	SIZE B	DWG No. 919-0550	REV G
			MODEL ASi/XPi		SCALE 1/1	SHEET 1 OF 1





REVISIONS					
REV	DATE	DESCRIPTION	DRAFTER	APPROVED	ECN
A	5-30-02	MODEL RELEASE	KT	JW	---
B	10-3-02	ADDED 4 .028 HOLES & TRACE : CHANGED J11 TO A 417-1701	KT	JW	10799
C	10-29-02	ADDED P5A-P12B; INDICATED L2-L9 & ADDED NOTES	KT	DK	10811
D	1-29-03	DEL R10 & R15	KT	DK	10870
E	5-16-03	CHGD JP5-JP12 TO 417-2600	KT	DK	10965
F	3-15-05	ADDED 4 0.171 HOLES	KT	DK	11265
G	5-16-05	CHGD JR1-JR8	KT		11285

NOTES:
1) * INDICATES COMPONENT STUFFED ON
SOLDER SIDE (L2-L9)

PROPRIETARY RIGHTS are included
in information disclosed herein.
This information is submitted
in confidence and neither this
document nor the information
disclosed herein shall be
reproduced or transferred to
other documents or used or
disclosed to others for manu-
facturing or for any other
purpose except as specifically
authorized in writing by
BROADCAST ELECTRONICS, INC.

TOLERANCE (DECIMAL) U.O.S.
.X ± .030 .XXX ± .005
.XX ± .015 ANGLES + 1°

DWN. BY
KT 5-31-02

DESIGNER(S)

PROJ. LEADER


MFG.

MATERIAL
SEE BOM
919-0551

FINISH

NEXT ASSY.


COPYRIGHT © 2002 BROADCAST ELECTRONICS, INC.


 BROADCAST ELECTRONICS INC.
4100 N. 24TH ST. P.O. BOX 3606 QUINCY, IL. 62305
217/224-9600 FAX 217/224-9607

TITLE
BNC XLR BOARD


TYPE	SIZE	DWG No.	REV
A	B	919-0551	G

MODEL NNNN	SCALE 1/1	SHEET 1 OF 1
------------	-----------	--------------






REVISIONS				DRAWN	APPROVED	ECN
REV	DATE	DESCRIPTION				
A	10-23-02	REDRAWN IN P-CAD; ENGINEERING RELEASE			KT	


PROPRIETARY RIGHTS are included in information disclosed herein. This information is submitted in confidence and neither this document nor the information disclosed herein shall be reproduced or transferred to other documents or used or disclosed to others for manufacturing or for any other purpose except as specifically authorized in writing by BROADCAST ELECTRONICS, INC.			DUN. BY KT 10-23-02		MATERIAL SEE BOM 919-0553			BROADCAST ELECTRONICS INC.						
			DESIGNER(S)		919-0553			4100 N. 24TH ST., P.O. BOX 3686 QUINCY, IL 62306 217/224-9600 FAX 217/224-9607						
TOLERANCE (DECIMAL) U.D.S. .xx ± .030 .xxx ± .005 .xxx ± .015 ANGLES ± 1°			PROD. LEADER		FINISH		TITLE TERMINAL STRIP, I/O INTERFACE							
			MFG.		NEXT ASSY.		TYPE S		SIZE D		DWS. NO. 919-0553		REV A	
							MODEL NNNNN		SCALE NONE		SHEET 1		OF 2	

COPYRIGHT © 2002 BROADCAST ELECTRONICS, INC.


B BROADCAST ELECTRONICS INC.
4100 N. 24TH ST., P.O. BOX 3606 QUINCY, IL. 62305
217/224-3606 FAX 217/224-3687

COPYRIGHT © 2002 BROADCAST ELECTRONICS, INC.





REVISIONS					
REV	DATE	DESCRIPTION	DRAFTER	APPROVED	ECN
A	5-23-02	MODEL RELEASE	KT	RH	----
B	9-18-02	ADDED R1,R2,P2,J2 & J3; ENGINEERING RELEASE	KT		10782



COPYRIGHT © 2002 BROADCAST ELECTRONICS, INC.

PROPRIETARY RIGHTS are included in information disclosed herein. This information is submitted in confidence and neither this document nor the information disclosed herein shall be reproduced or transferred to other documents or used or disclosed to others for manufacturing or for any other purpose except as specifically authorized in writing by BROADCAST ELECTRONICS, INC.

DWN. BY
KT 5-23-02
DESIGNER(S)
RH 5-23-02

PROJ. LEADER

MFG.

MATERIAL
SEE BOMS
919-0557
919-0557-001

FINISH

NEXT ASSY.

BE® BROADCAST ELECTRONICS INC.
4100 N. 24TH ST., P.O.BOX 3606 QUINCY, IL. 62305
217/224-9600 FAX 217/224-9607

TITLE
FRONT PANEL LED BOARD

TYPE S	SIZE A	DWG. NO. 919-0557/-001	REV B
-----------	-----------	---------------------------	----------

MODEL FM-IBOC	SCALE NONE	SHEET 1 OF 1
---------------	------------	--------------

TOLERANCE (DECIMAL) U.O.S.
.x ± .030 .xxx ± .005
.xx ± .015 ANGLES ± 1°

		REVISIONS				
REV	DATE	DESCRIPTION	DRAFTER	APPROVED	ECN	
A	5-23-02	MODEL RELEASE	KT		----	
B	8-15-02	CORRECTED DETAIL	KT		----	
C	9-18-02	ADDED R1 ,R2 ,J2 ,J3 ,P2; ENGINEERING RELEASE	KT		10782	

LED REF.

441-0009

519-0557

DETAIL "A"

SEE NOTE 3

SEE DETAIL "A"

TYP. 2 PLCS.

FLAT SIDE OF LED

TYP. 2 PLCS.

NOTES:

1: J1,J2,J3,R1,R2 ARE MOUNTED ON THE SOLDER SIDE.

2: * INDICATES R1,R2 ARE NOT MOUNTED ON 919-0557.

3: P2 IS INSTALLED ON J2 FOR 919-0557.


P2 IS INSTALLED ON J3 FOR 919-0557-001.

COMPONENT	919-0557	919-0557-001
LED1	323-9224	323-9224
LED2	323-9217	323-9224

COPYRIGHT © 2002 BROADCAST ELECTRONICS, INC.

<p>PROPRIETARY RIGHTS are included in information disclosed herein. This information is submitted in confidence and neither this document nor the information disclosed herein shall be reproduced or transferred to other documents or used or disclosed to others for manufacturing or for any other purpose except as specifically authorized in writing by BROADCAST ELECTRONICS, INC.</p> <p>TOLERANCE (DECIMAL) U.O.S.</p> <p>.X ± .030 .XXX ± .005</p> <p>.XX ± .015 ANGLES + 1°</p>	<p>DWN. BY</p> <p>KT 5-23-02</p>	<p>MATERIAL</p> <p>SEE BOMS</p> <p>919-0557</p> <p>919-0557-001</p>	<p>BE® BROADCAST ELECTRONICS INC.</p> <p>4100 N. 24TH ST. P.O.BOX 3606 QUINCY,IL. 62305</p> <p>217/224-9600 FAX 217/224-9607</p>									
	<p>DESIGNER(S)</p>	<p>FINISH</p>	<p>TITLE</p> <p>FRONT PANEL LED BOARD</p>									
	<p>PROJ. LEADER</p>	<p>NEXT ASSY.</p>	<table><thead><tr><th>TYPE</th><th>SIZE</th><th>DWG No.</th><th>REV</th></tr></thead><tbody><tr><td>A</td><td>A</td><td>919-0557/-001</td><td>C</td></tr></tbody></table>		TYPE	SIZE	DWG No.	REV	A	A	919-0557/-001	C
	TYPE		SIZE	DWG No.	REV							
A	A	919-0557/-001	C									
<p>MFG.</p>	<table><tbody><tr><td>MODEL NNNN</td><td>SCALE 1/1</td><td>SHEET 1 OF 1</td></tr></tbody></table>	MODEL NNNN	SCALE 1/1	SHEET 1 OF 1								
MODEL NNNN	SCALE 1/1	SHEET 1 OF 1										

REVISIONS					
REV	DATE	DESCRIPTION	DRAFTER	APPROVED	ECN
A	7-2-02	PROTOTYPE RELEASE/MODEL RELEASE	KT	JT	----
B	2-9-05	ADDED R1	KT		11251




COPYRIGHT © 2002 BROADCAST ELECTRONICS, INC.

PROPRIETARY RIGHTS are included in information disclosed herein. This information is submitted in confidence and neither this document nor the information disclosed herein shall be reproduced or transferred to other documents or used or disclosed to others for manufacturing or for any other purpose except as specifically authorized in writing by BROADCAST ELECTRONICS, INC.


TOLERANCE (DECIMAL) U.O.S.
.x ± .030 .xxx ± .005
.xx ± .015 ANGLES ± 1°

DWN. BY KT 7-2-02
DESIGNER(S)
PROJ. LEADER
MFG.

MATERIAL SEE BOM 919-0558
FINISH
NEXT ASSY.


 BROADCAST ELECTRONICS INC. 4100 N. 24TH ST., P.O. BOX 3606 QUINCY, IL. 62305 217/224-9600 FAX 217/224-9607			
TITLE LCD POWER			
TYPE S	SIZE A	DWG. NO. 919-0558	REV B
MODEL NNNN		SCALE NONE	SHEET 1 OF 1

REVISIONS					
REV	DATE	DESCRIPTION	DRAFTER	APPROVED	ECN
A	7-3-02	MODEL RELEASE	KT		----
B	2-10-05	ADDED R1	KT		11251



NOTES:
1) DASHED OUTLINE COMPONENTS
PLACED ON SOLDER SIDE:
(C1,J1,U1)

COPYRIGHT © 2002 BROADCAST ELECTRONICS, INC.

PROPRIETARY RIGHTS are included in information disclosed herein. This information is submitted in confidence and neither this document nor the information disclosed herein shall be reproduced or transferred to other documents or used or disclosed to others for manufacturing or for any other purpose except as specifically authorized in writing by BROADCAST ELECTRONICS, INC.	DWN. BY KT 7-3-02	MATERIAL SEE BOM 919-0558	 BROADCAST ELECTRONICS INC. 4100 N. 24TH ST. P.O.BOX 3606 QUINCY, IL. 62305 217/224-9600 FAX 217/224-9607		
	DESIGNER(S)				
	PROJ. LEADER	FINISH	TITLE LCD POWER SUPPLY		
	MFG.	NEXT ASSY.	TYPE A	SIZE A	DWG No. 919-0558
TOLERANCE (DECIMAL) U.O.S. .X ± .030 .XXX ± .005 .XX ± .015 ANGLES + 1°			MODEL NNNN		SCALE 1/1
			SHEET 1 OF 1		REV B